



User Manual

1. Product Overview



2. What's in the package



3. Attention

- Please charge earbuds before wearing them according to user guidance.
- Please do not hit earbuds and charging case severely.
- Please do not expose earbuds to benzene and other diluent chemicals.
- Please do not disassemble, repair or modify by yourself.
- Please do not listen at high volume for a long time to avoid hearing impairment.
- Please do not expose earbuds to the sun for long.
- Please do not keep earbuds in water or damp places for long periods of time.

4. Technical Specifications

Bluetooth version: V5.1, auto power on, auto pairing & connection
Bluetooth device name: TWS-T04S, English voice prompt available
Effective range: up to 10 meters
Waterproof: IPX5
Sound channel: dual channel stereo
Battery: lithium-ion battery
Earbuds battery: 3.7V, 60mAh
Charging case battery: 3.7V, 300mAh, able to provide 2 charges to earbuds
Music time: 8H
Frequency response: 20Hz ~ 20KHz
Material: Plastic

5. Earbuds Wearing and Bluetooth Connection

5.1 Wear earbuds

- ① Take earbuds from charging case, and refer to "L" and "R" on earbuds to wear them on left/right ear respectively.
- ② Please try different ear tips (large / medium / small) for your own comfortability.
- ③ Press the earphone gently into the auricle to ensure better sound effect.

5.2 Bluetooth connection

- ① Auto power on: The earbuds will be automatically turned on the moment they are taken out from charging case.
And you will hear voice prompts as below:
Frequency response: 20Hz ~ 20KHz
Right: a) Power on
b) Du (indicating that left and right earbuds are connected)
Left: a) Power on
b) Du (indicating that left and right earbuds are connected)
...

- ② Turn on Bluetooth on your mobile device
Go to settings → Go to Bluetooth → Turn on Bluetooth → Scan for Bluetooth devices → Select "TWS-T04S" (Voice prompt "connected")

5.3 How to pair with another Bluetooth device

- ① Unpair earbuds from currently paired device.
- ② Follow the same pairing guideline with another device.

6. Music Playback

- ① Open music app on your mobile when paired.
- ② Touch either earbud twice to play/pause music.
- ③ Touch left earbud three times to switch to the previous track, and right earbud three times to the next track.



7. Answer call


- ① When you receive an incoming call, touch (or long press) either earbud once to answer an incoming call.
- ② Touch either earbud twice during a phone call to hang up.

8. Charging


Charging case

Fully charged case can provide charges to earbuds.

- ① Insert the Micro USB end of the cable into the Micro USB charging port on charging case.



LED Status for charging case battery:
Blinking red: charging
Solid red: fully charged



Micro USB charging port

- ② Insert the USB A end of the cable into a charger for power.



Earbuds

Fully charged earbuds can provide up to 8 hours music time.

- ① The red LED indicator will blink when the earbud battery power is low.
- ② Place the earbuds into the charging case to get charged.
- ③ Take out the earbuds from the charging case when fully charged, and they will auto connect to each other.



Status LED for earbuds
Red LED: charging
LED off: fully charged

9. Trouble shooting

- ① **Bluetooth device cannot be found on mobile phones.**
 - a) Check whether left and right earbuds are paired successfully.
 - b) If earbuds are still unable to pair with Bluetooth device, please place earbuds into charging case and take out again, during which process Bluetooth earbuds will restart simultaneously.
- ② **Earbuds are frequently disconnected from Bluetooth device after their connection.**
 - a) Earbuds battery power is insufficient. Please charge earbuds as soon as possible.
 - b) The distance between Bluetooth device and earbuds has exceeded effective range.
- ③ **Do I need to search Bluetooth earbuds and connect them to my Bluetooth device each time for use?**

No, you needn't. Once paired, earbuds will automatically connect to the previously connected device.
- ④ **Do I need to turn on and turn off earbuds manually before and after use?**

No, you needn't. Earbuds will be auto on, when they are taken out from charging case, and be auto off & start charging when they are put into charging case.

- ⑤ **If earbuds are taken out from charging case and not used for a long time, will earbuds stay on till battery is drained then off?**

No, earbuds will turn off automatically in 5 minutes when they are not in use.

10. FCC warnings

FCC ID: A4X-TWST04S

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions: (1) the device must not cause harmful interference, and (2) the device must accept any interference received which may cause it to malfunction. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not shielded and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
- Reorient the receiving antenna.
- Move the equipment away from the receiver and/or reorient the receiver.
- Consult the equipment user's manual and dealer for a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.
Changes or modifications not expressly approved by the party responsible for compliance could void your authority to operate the equipment.