


Nice to meet you!

Divoom-Macchiato – Incredible sound for its size

Like a cup of fine brewed coffee, Divoom-Macchiato has a refined taste in both music and design. Equipped with a 6W DSP-Tuned speaker and radio tuner, it sounds just as good as it look. Powered by a 1400mAh battery, it offers 8 hours non-stop music play. It's time to enjoy the great audio.



What's included?

- Divoom-Macchiato
- User manual
- Micro USB charging cable
- Antenna

Thank you for purchasing a Divoom product! Please read this manual carefully. You can also visit divoom.com to learn more about our other products!

Due to the nature of the technology product, the instructions on this manual are subject to change without prior notice. If you have any questions, please feel free to contact the Divoom customer support.



Product details

TOP

1. Volume + button
2. Volume - button
3. Play/Pause button

SIDE

4. Charge Port
5. Power button



Button functions (Bluetooth mode/FM Radio mode)

Bluetooth mode

TOP

1. Volume +:
Press: Increase volume
Hold: Skip track
2. Volume -:
Press: Decrease volume
Hold: Previous track
3. Play:
Press: Play/Pause music
Hold: Disconnect Bluetooth

SIDE

4. Power:
Press: Switch Bluetooth or Radio mode
Hold: Power ON/OFF


FM Radio mode

TOP

1. Volume +:
Press: Increase volume
Hold: Next station
2. Volume -:
Press: Decrease volume
Hold: Previous station
3. Play:
Press: Play/Mute sound
Hold: Scan FM radio stations

SIDE

4. Power:
Press: Switch Bluetooth or Radio mode
Hold: Power ON/OFF



How to connect in Bluetooth?

1. Power on the speaker.
2. In the phone's Settings, please turn on the Bluetooth.
3. Search and connect with the 'Divoom-Macchiato'.
4. Once paired, you can start to play music.


How to attach/detach the leather strap?

1. Insert one of the leather strap head into the speaker side handle
2. Line up and push the leather strap into the speaker side molding
3. Repeat the same steps for the other end of the leather strap

* To detach, please reverse the above steps.

How to setup the Radio?

1. Power on the speaker (insert antenna stick for better signal strength)
2. Press the power button again to switch to the FM radio mode.
3. Hold the play button to scan all available stations (Stations automatically stored after the first search. Scan again will replace previously store stations).
4. Hold the volume buttons to change channel, and enjoy the radio.



How to insert the FM radio signal stick?

- 1.Line up and insert the signal stick into the USB port
- 2.Please be careful during installation and removal of the signal stick.

- * Do not force the stick into the USB port.
- * Do not handle/carry the speaker with the inserted signal stick.
- * Improper operation will cause permanent damage to the USB port.

Note: In some remote mountainous areas, the signal is not good, the signal is not good, so the external FM antenna is used to enhance the receiving signal.

More set up information

How to charge the Macchiato?

- 1.Insert the USB cable into the side of the speaker.
You can continue to listen to music while charging.
- 2.The charging time may vary by the type of USB charger.
We recommend using the 1.0A charger for optimal charging time.

How to make call with hands-free mode?

- 1.Press the play button to pick up an incoming call,
and press the play button to end call.
- 2.Hold the play button to reject the incoming call.

Product specification

Specification details:

Dimension (mm): 95.7L x 53W x 64.7H
Weight:298g
Speaker size:40mm
Output power:6W
Frequency response:80-20KHz
Signal-to-noise ratio:>=85dB
Playback time:up to 6hrs
Battery capacity:1400mAh
Battery voltage:3.7V
Wireless range:up to 10 meters/33 feet
Bluetooth compliant: **V4.2**

Safety guide

Please read the following instructions carefully:

- Please follow our product installation and operation instructions.
- Always place the speaker on a smooth and stable surface.
- Please place the speaker on an open area for the best sound quality.
Do not block the surroundings of the speaker.
- Do not push any objects into speaker vents or slots.
Do not apply any great force on the speaker.
- Please keep the speaker at a room temperature environment.
Do not place the speaker near any heat sources (such as radiators, heat registers, stoves, fire place, or direct sunlight).
Do not place the speaker near any open flame source.
- Do not attempt to service the speaker by yourself. Always refer to the instructions by qualified service personnel.
- To avoid the risk of electrical hazard, do not expose this speaker to wet surface.

DECLARATION OF CONFORMITY:



This device meets the essential requirements of the following Directive 2014/53/EU of the European parliament of the council of 16 April 2014.



The waste container symbol with the X through it on the device indicates that the device must be disposed of separately from normal domestic waste at an appropriate waste disposal facility at the end of its useful service life

Limited Warranty

1. If within 12 months of purchase this device or any part thereof is proven to be defective by reason of faulty workmanship or defects in materials, we will at our option repair or replace the same free of charge of labor or materials on condition that.
2. The original invoice or sales receipt with the date of purchase, or stamp from the dealer is presented together with the defective unit.
3. The warranty does not cover product failures which have been caused by use of accessories other peripheral devices which are not DIVOOM branded original accessories intended for use with the product.
4. The warranty does not cover product failures caused by:
Modification, repaired, and disassembled by any person who is not authorized by the manufacturer.
Any defective unit or part shall become property of the manufacturer.
The warranty does not cover any damage caused by misuse, drop, hit or neglect.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
 - (2) this device must accept any interference received, including interference that may cause undesired operation.
- changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.


NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

终于等到你！Nice To Meet You.

Divoom-Macchiato – 音乐传递美好酷滋味

Divoom-Macchiato 是Divoom旗下新款小型便携蓝牙无线音箱。TA除了有完美优雅的外观设计，还有专业调教的优质音质，以及FM电台收音功能。



配件清单：

- Divoom-Macchiato
- 使用指南
- Micro USB充电线
- 天线

使用前请仔细阅读使用说明书，如需了解更多产品信息。请浏览官网www.Divoom.com
本公司产品在不断的精进中，如有规格或细节调整原则不另行说明，请与实物为准。敬请谅解。



产品示意图

顶部

1. 增音量键
2. 减音量键
3. 播放键

侧面

4. 充电孔
5. 开关键



产品按键介绍（蓝牙模式/FM收音模式）

蓝牙模式

顶部

- 1.增音量键：
短按：增加音量
长按：下一首歌
- 2.减音量键：
短按：降低音量
长按：上一首歌
- 3.播放键：
短按：播放/暂停
长按：切断蓝牙

侧面

- 4.开关键：
短按：切换蓝牙或FM收音模式
长按：开关音箱


Fm收音模式

顶部

- 1.增音量键：
短按：增加音量
长按：下一电台
- 2.减音量键：
短按：降低音量
长按：上一电台
- 3.播放键：
短按：播放/静音
长按：搜索电台

侧面

- 4.开关键：
短按：切换蓝牙或FM收音模式
长按：开关音箱




如何连接蓝牙？

- 1.音箱开机后，打开手机蓝牙功能。
- 2.搜索并配对'Divoom-Macchiato'
- 3.配对成功后，即可播放音乐。

如何播放电台音乐？

- 1.音箱开机后（可插入天线增强信号）。
- 2.短按开关键切换至FM收音模式。
- 3.长按播放键搜索FM电台（仅需搜索一次即可储存搜索结果。再次搜索会清空及替换之前存储电台）。
- 4.长按音量键可进行调台，按播放键可即刻静音。



如何安裝和拆除音箱皮帶？

- 1.把皮帶的一端插入音箱側面的空槽
- 2.確認機身的固定點與皮帶洞對齊後，把皮帶往下壓並固定皮帶
- 3.為皮帶另一端重復上述步驟

* 如需拆除音箱皮帶，請拉起皮帶兩端即可取出音箱皮帶

如何安裝收音機天線？

- 1.請確認該機並非在充電
- 2.對準插口後，小心插入天線接頭至USB插口

* 請勿強行插入天線，強行插入可能USB插口破損，從而無法充電
* 天線只供增強信號使用，不做承重設計，切勿懸空提拉。
不正當使用可造成USB插口或天線鬆動及破損

注：有些偏遠的山區，信號不好，所以外接FM天線是為了加強接收信號

產品使用方法

如何接聽來電？

- 1.短按播放鍵接聽來電。通話結束後，再次短按播放鍵結束來電
- 2.如需回絕來電，請長按播放鍵。

如何充電？

- 1.插入機身側面Micro USB充電線。充電同時可聽歌。
- 2.充電時長取決於充電配件功率，建議使用5V-1A以上或充電裝置。

產品規格


尺寸：	95.7L x 53W x 64.7H mm
重量：	298g
喇叭尺寸：	40mm
輸出功率：	6W
響應頻率：	80-20KHz
信噪比：	≥80dB
播放時長：	10小時以上
電池容量：	1400mAh
電池電壓：	3.7V
藍牙距離：	10米
藍牙版本：	V4.2

安全指引及注意事項

使用前請務必仔細閱讀此說明書，請按照說明書內容操作使用

- 1.請將音箱放在平穩、安全的地方，避免掉落造成損傷或者造成人員受傷。
- 2.保持音箱周邊有足夠的空間以獲得最佳音質表現。
- 3.請勿將任何異物插入音箱鐵網或插孔。
- 4.請勿大力敲擊音箱或用外力撞擊音箱。
- 5.遠離熱源，不要靠近明火、微波爐、電暖氣等會產生高熱的電器，確保安全，
只能使用隨附的配件。
- 6.如有任何問題請與原廠商或者代理商聯絡，諮詢專業的維修人員處理解決。

歐盟符合性聲明：

 本設備符合2014年4月16日理事會歐洲議會的
以下指令2014/53 / EU的基本要求。

产品中有害物质的名称及含量

Names and Contents of Hazardous Substances

为满足中华人民共和国电器产品有害物质限制相关的法律法规和其他要求，公司对本产品中有害物质，声明如下：

部件名称 Name of the Parts	有害物质 Hazardous Substance					
	铅(Pb, Lead)	汞(Hg, Mercury)	镉(Cd, cadmium)	六价铬 (Chromium(VI))	多溴联苯 (PBB)	多溴二苯醚 (PBDE)
Housing 外壳	○	○	○	○	○	○
Loudspeakers 喇叭单元	○	○	○	○	○	○
PWBs 电路板组件	○	○	○	○	○	○
Accessories (Cables) 附件 (连接线)	X	○	○	○	○	○

本表格依据SJ/T 11364的规定编制。

○：表示该有害物质在该部件所有均质材料的含量均在GB/T 26572标准规定的限量要求下。

X：表示该有害物质至少在该部件的某一均质材料中的含量超出GB/T 26572标准规定的限量要求。

注：表中标记“X”的部件，皆因全球技术水平限制而无法实现有害物质的代替



在中华人民共和国境内销售的电子电气产品必须标识此标志，标志内的数字代表在正常使用的状态下的产品的环保使用期限。

产品质保回执单

质保服务只限于保修期范围内

商品名称		商品型号	
购买渠道		购买日期	
用户姓名		联系电话	
用户地址			

全国技术咨询电话：

JD：<https://mall.jd.com/index-130830.html>

网上售后服务及售后咨询：0755-29494509

TMALL：<https://divoom.tmall.com>

制造商：广东深圳市战音科技有限公司

官方网站：www.Divoom.com

制造商地址：广东深圳市宝安区沙井街道和一西部新联河工业园5栋厂房第一层东边

保修条款：

购买战音产品保修条例如下：

本产品有效保修期为自出售之日起一年内在保修期限内正常使用和维护下，无人为损坏，机器本身机件材料及功能出现问题，发生故障，无法正常使用，本公司将提供免费修理及更换零件。在使用过程中若发现问题请及时与官方旗舰店联系以便及时售后处理。本产品的保修不适用于：

- 1：设备，部件已超出保修期。
- 2：用户未按照说明书指南要求，错误操作及保管不当使设备故障或损坏。
- 3：因意外因素或者人为因素（包括如操作失误，刮伤，跌落等导致的设备故障或损坏）
- 4：因自然灾害等不可抗力（如地震，火灾）原因造成产品的故障或损害。
- 5：非本公司授权修理者拆过的。

沿虚线剪下寄回本公司客户服务部

Divoom[®]

Product name: Bluetooth Speaker

Product model: Macchiato

Manufacturer: Shenzhen Divoom Technology Co.,LTD.

Frequency Range: 2.4GHZ-2.48GHZ,

Max. Transmit Power: BT4.2 : -2.66 dBm Max

SIMPLIFIED EU DECLARATION OF CONFORMITY

The simplified EU declaration of conformity referred to in Article 10(9) shall be provided as follows:

Hereby, Shenzhen Divoom Technology Co.,LTD. declares that radio equipment type Tivoo is in compliance with Directive 2014/53/EU, and this product is allowed to be used in all EU member states.

The full text of the EU declaration of conformity is available at following company website:<http://www.divoom.com>

FM Frequency:88~108MHz

Casa Innovations Inc

address:155 Bay Ridge Ave, Brooklyn, NY 11220

phone:718-812-6676

Contact::Aron Abramson

email:aron@casa-innovations.com