



Mode 2: IEEE 802.11b Continuous TX mode\_ANT-0

2412 MHz



2437 MHz




2462 MHz





Mode 3: IEEE 802.11g Continuous TX mode\_ANT-0

2412 MHz



2437 MHz




2462 MHz





Mode 4: IEEE 802.11n 2.4 GHz 20 MHz Continuous TX mode \_ANT-0


2412 MHz



2437 MHz



2462 MHz









Mode 5: IEEE 802.11n 2.4 GHz 40 MHz Continuous TX mode \_ANT-0


2422 MHz



2437 MHz




2452 MHz





Mode 6: IEEE 802.11ax 2.4 GHz 20 MHz Continuous TX mode\_ANT-0

2412 MHz



2437 MHz




2462 MHz





Mode 7: IEEE 802.11ax 2.4 GHz 40 MHz Continuous TX mode\_ANT-0

2422 MHz



2437 MHz



2452 MHz








Mode 2: IEEE 802.11b Continuous TX mode\_ANT-1

2412 MHz



2437 MHz




2462 MHz






Mode 3: IEEE 802.11g Continuous TX mode\_ANT-1


2412 MHz



2437 MHz



2462 MHz








Mode 4: IEEE 802.11n 2.4 GHz 20 MHz Continuous TX mode \_ANT-1


2412 MHz



2437 MHz




2462 MHz






Mode 5: IEEE 802.11n 2.4 GHz 40 MHz Continuous TX mode\_ANT-1


2422 MHz



2437 MHz



2452 MHz





Mode 6: IEEE 802.11ax 2.4 GHz 20 MHz Continuous TX mode\_ANT-1


2412 MHz



2437 MHz



2462 MHz









Mode 7: IEEE 802.11ax 2.4 GHz 40 MHz Continuous TX mode\_ANT-1

2422 MHz



2437 MHz



2452 MHz









Mode 3: IEEE 802.11g Continuous TX mode\_ANT-2

2412 MHz



2437 MHz



2462 MHz









Mode 4: IEEE 802.11n 2.4 GHz 20 MHz Continuous TX mode \_ANT-2


2412 MHz



2437 MHz




2462 MHz






Mode 5: IEEE 802.11n 2.4 GHz 40 MHz Continuous TX mode \_ANT-2


2422 MHz



2437 MHz




2452 MHz





Mode 6: IEEE 802.11ax 2.4 GHz 20 MHz Continuous TX mode\_ANT-2

2412 MHz



2437 MHz



2462 MHz








Mode 7: IEEE 802.11ax 2.4 GHz 40 MHz Continuous TX mode\_ANT-2


2422 MHz



2437 MHz



2452 MHz





Mode 2: IEEE 802.11b Continuous TX mode\_ANT-3

2412 MHz



2437 MHz




2462 MHz






Mode 3: IEEE 802.11g Continuous TX mode\_ANT-3


2412 MHz



2437 MHz



2462 MHz









Mode 4: IEEE 802.11n 2.4 GHz 20 MHz Continuous TX mode\_ANT-3


2412 MHz



2437 MHz




2462 MHz





Mode 5: IEEE 802.11n 2.4 GHz 40 MHz Continuous TX mode\_ANT-3


2422 MHz



2437 MHz



2452 MHz





Mode 6: IEEE 802.11ax 2.4 GHz 20 MHz Continuous TX mode\_ANT-3


2412 MHz



2437 MHz



2462 MHz








Mode 7: IEEE 802.11ax 2.4 GHz 40 MHz Continuous TX mode\_ANT-3


2422 MHz



2437 MHz



2452 MHz








Mode 5: IEEE 802.11n 2.4 GHz 40 MHz Continuous TX mode \_ANT-0


2422 MHz



2437 MHz



2452 MHz









Mode 6: IEEE 802.11ax 2.4 GHz 20 MHz Continuous TX mode\_ANT-0


2412 MHz



2437 MHz




2462 MHz






Mode 7: IEEE 802.11ax 2.4 GHz 40 MHz Continuous TX mode\_ANT-0

2422 MHz



2437 MHz



2452 MHz

