


SAR Exclusion Calculation

Antenna Location



Measurement from the top side of the PCB where the PCB etch antenna is located. The distance is measured from the antenna to the bottom foot because that is the closest distance to a customer in a body worn condition if they were to use the included strap to attach the EUT to their belt. If it were not for the potential to attach to a belt this product would be a portable product and we would be applying for the more lenient MPE exemption instead of SAR exemption.