


1) Module location



Open the bottom panel



WLAN/Bluetooth module

## 2) Antenna Location

