


Attachment 7.

- DUT Antenna Information and SAR Test SETUP PHOTOGRAPHS
DUT Antenna Information

Tablet Mode

Fig.1 Size of the device (Tablet)


Unit: mm



Laptop Mode


Fig.2 Size of the device (Laptop mode)

CF-33 can use laptop computer with the base unit.
The base unit provides keyboard, Input/output interfaces (USB, LAN, SD card, DC-Input and so on)



convertible Mode

Fig.3 Size of the device (Convertible mode)



Note :SAR for the dent region of the laptop was not measured based on guidance from the FCC

SAR Test Setup Photographs

■ Test Setup Photo (Body Rear All)



■ **Test Setup Photo (Rear Side)**



[Distance of 0 mm from the EUT]

■ **Test Setup Photo (Rear Side)**



[Distance of 20 mm from the EUT]

■ **Test Setup Photo (Rear Side)**



[Distance of 20 mm from the EUT]

■ **Test Setup Photo (Rear Side)**



[Distance of 21 mm from the EUT]

■ **Test Setup Photo (Rear Side)**



[Distance of 21 mm from the EUT]

■ Test Setup Photo (Body Edge1 All)



■ **Test Setup Photo (Edge1 Side)**



[Distance of 0 mm from the EUT]

■ **Test Setup Photo (Edge1 Side)**



[Distance of 37 mm from the EUT]

■ **Test Setup Photo (Edge1 Side)**



[Distance of 37 mm from the EUT]

■ **Test Setup Photo (Edge1 Side)**



[Distance of 39 mm from the EUT]

■ **Test Setup Photo (Edge1 Side)**



[Distance of 39 mm from the EUT]

■ **Test Setup Photo (Body Edge2 All)**



■ **Test Setup Photo (Edge2 Side)**



[Distance of 0 mm from the EUT]

■ **Test Setup Photo (Edge2 Side)**



[Distance of 0 mm from the EUT]

■ **Test Setup Photo (Edge2 Tilt Side)**



[Distance of 0 mm from the EUT]

■ **Test Setup Photo (Body Edge4 All)**



■ **Test Setup Photo (Edge4 Side)**



[Distance of 0 mm from the EUT]

■ **Test Setup Photo (Edge4 Side)**



[Distance of 0 mm from the EUT]

■ **Test Setup Photo (Edge4 Tilt Side)**



[Distance of 0 mm from the EUT]