

#### 4.3. Photographs of EUT System Configuration

Maximum operation mode

FRONT VIEW



- Continued -

Maximum operation mode

LEFT SIDE VIEW



- Continued -

Maximum operation mode

RIGHT SIDE VIEW

