





Inside of housing.




EUT Inside view with housing disassembled




EUT Antenna





Bottom of PCB, shows battery compartment and antenna.



Component side of PCB