

character

487 Bryant Street, 3rd Floor San Francisco CA 94107 415 227 2100

CLIENT: Dropcam

PROJECT: Dropcam Pro Packaging—Quick Start Guide

DATE: 07/11/2013

FILE NAME: Dropcam_QSG-HD-P-01.ai

SCALE: 100%

INKS & FINISHES:

Four Color Process + PMS 2925 C + PMS Cool Gray 10 C

Welcome to Dropcam.

Quick Start Guide

- 1 Connect camera to your computer's USB port.
Note: Camera's status light will blink yellow as it connects.



- 2 Find the launch icon (📍). Double click to begin.

Windows: Select "Open folder to view files" from the AutoPlay window, or go to "My Computer" to find the launch icon.

Mac: Select the launch icon on your desktop, or open Finder and select "Dropcam" from the left sidebar.

- 3 Follow the simple instructions on screen to complete the setup process.

Important: Please do not unplug camera from computer until prompted.

Don't have a computer handy?
Try our mobile setup using one of our mobile apps:



Need help? Contact our support team at:
www.dropcam.com/support
1-877-345-3767 (Mon-Sat, 6am-6pm PT)

QSG-HD-P-01

P/N: 2520AD610L-B02 FCC WARNING CARD (DROPCAM PRO)(REV B)



材質：80G模造紙
尺寸：84x183 mm
單黑1+1