

Owner's Manual

Important!
Return your Warranty Registration
Card within 10 days. See







PHILIPS

Return your Warranty Registration card today to ensure you receive all the benefits you're entitled to.

Once your PHILIPS purchase is registered, you're eligible to receive all the privileges of owning a PHILIPS product. So complete and return the Warranty Registration Card enclosed with your purchase at once. And take advantage of these important benefits.

Warranty Verification

Registering your product within 10 days confirms your right to maximum protection under the terms and conditions of your PHILIPS warranty.

Owner Confirmation

Your completed Warranty Registration Card serves as verification of ownership in the event of product theft or loss.

Model Registration

Returning your Warranty
Registration Card right away guarantees you'll receive all the information
and special offers which you qualify
for as the owner of your model.

PHILIPS

Congratulations on your purchase, and welcome to the "family!"

Dear PHILIPS product owner:

Thank you for your confidence in PHILIPS. You've selected one of the best-built, best-backed products available today. And we'll do everything in our power to keep you happy with your purchase for many years to come.

As a member of the PHILIPS "family," you're entitled to protection by one of the most comprehensive warranties and outstanding service networks in the industry.

What's more, your purchase guarantees you'll receive all the information and special offers for which you qualify, plus easy access to accessories from our convenient home shopping network.

And most importantly you can count on our uncompromising commitment to your total satisfaction.

All of this is our way of saying welcome-and thanks for investing in a PHILIPS product.

Sincerely,



Robert Minkhorst
President and Chief Executive Officer

P.S. Remember, to get the most from your PHILIPS product, you must return your Warranty Registration Card within 10 days. So please mail it to us right now! Know these **safety** symbols



This "bolt of lightning" indicates uninsulated material within your unit may cause an electrical shock. For the safety of everyone in your household, please do not remove product covering.

The "exclamation point" calls attention to features for which you should read the enclosed literature closely to prevent operating and maintenance problems.

WARNING: TO PREVENT FIRE OR SHOCK HAZARD, DO NOT EXPOSE THIS EQUIPMENT TO RAIN OR MOISTURE.

CAUTION: To prevent electric shock, match wide blade of plug to wide slot, fully insert.

ATTENTION: Pour éviter les choc électriques, introduire la lame la plus large de la fiche dans la borne correspondante de la prise et pousser jusqu'au fond.

For Customer Use

Enter below the Serial No. which is located on the rear of the cabinet. Retain this information for future reference.

Model No.	
Serial No.	



PHILIPS

Visit our World Wide Web Site at http://www.philips.com

Welcome to your TV/VCR owner's manual.

This manual describes two models: CCB134 and CCB194. Although the models may have a different appearance, all models operate exactly the same. The features described in this manual apply to all models unless otherwise specified. The CCB 34 is illustrated in this manual, but the another model has a similar appearance.

This manual has seven sections: Setting Up Your TV/VCR; Description of Controls; Basic Operations; Recording Options; Playing Options; Additional Features; and Information You May Need. The instructions explain all of the TV/VCR's features, which are listed below.

Features

- A-B Repeat Play
- Automatic Head Cleaner
- Automatic Tracking Adjustment
- Blue Background
- Closed Caption
- Daylight-Savings Time
- FM Radio
- Index Search
- 19 micron head, improves the picture quality during playback of SLP tapes
- On-screen displays in English or Spanish
- On-screen Menu Programming, accessible with remote control or front panel buttons
- One-Touch Recording

- Remote Control with capability to operate a Cable Box or Direct Broadcast System
- Remote Locator
- Repeat Play
- S-VHS Quasi Play Back (SQPB)
- ShowGuard™ Indefinite Timer Recording memory
- Skip Search
- Sleep Timer
- Smart Sound
- SmartClock™
- SmartLock™
- SmartPicture™
- Timer Recording
- VCR Plus+ Programming System
- Wake Up Timer

Safety Precautions

Warning: To prevent fire or shock hazard, do not expose this equipment to rain or moisture.

Federal Communications Commission (FCC) Warning: Any unauthorized changes or modifications to this equipment void the user's authority to operate it.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This TV/VCR, equipped with a High Quality (HQ) system, is compatible with existing Video Home System (VHS) equipment.

Note to the Cable TV System Installer: This reminder is provided to call the Cable TV system installer's attention to Article 820-40 of the National Electrical Code, which provides guidelines for proper grounding - in particular, specifying that the cable ground shall be connected to the grounding system of the building, as close to the point of cable entry as possible.

Declaration of Conformity

Model Number:

CCB134AT/CCB194AT

Trade Name:

Philips

Philips Consumer Electronics Responsible Party:

P.O. Box 14810

Knoxville, TN 37914-1810

(865) 521-4316

As an ENERGY STAR® Partner, Philips Consumer Electronics Company has determined that this product meets the ENERGY STAR® guidelines for energy efficiency. ENERGY STAR® is a U.S. registered mark. Using products with the ENERGY STAR® label can save energy. Saving energy reduces air pollution and lowers utility bills.

SmartClock™, SmartPicture™, SmartLock™, and ShowGuard™ are trademarks of Philips Consumer Electronics Company.

Copyright 2000 Philips Consumer Electronics Company. All rights reserved. VCR Plus+® and PlusCode® are registered trademarks of Gemstar Development Corporation. The VCR Plus+ system is manufactured under license from Gemstar Development Corporation.

Section 15.21

Section 15.19 (a)

Helpful Hints

- Before doing anything else, record the TV/VCR's model and serial numbers in the spaces provided on page two.These numbers will help us assist you if you ever call for help.
- Your new product, its packaging, and this manual contain materials that can be recycled and reused. Specialized companies can recycle your product to increase the amount of reusable materials and to minimize the amount that needs to be properly disposed. Your product uses batteries that should not be thrown away when depleted but should be disposed of as small chemical waste. Please find out about the local regulations on disposal of your old product, batteries, manual, and packaging whenever you replace existing equipment.

4 Table of Contents

Setting Up Your TV/VCR
Introduction
Table of Contents
Before Using the TV/VCR5
Hooking Up the TV/VCR
Turning On the TV/VCR
Language Selection
Automatic Channel Setup10-11
Setting the Clock
Daylight-Savings Time
Time Zone
Setting the Remote to Operate a Cable Box/DBS
Description of Controls
Front Panel
Rear Panel
Remote Control Buttons
Adjusting the Picture Controls
On-Screen Status Displays
Basic Operations
Playing
Recording
Recording Options
One-Touch Recording
Rerecording (Tape Duplication)
Defeat Recording
Timer Recording
Setting Up the VCR Plus+ Programming System
Timer Recording With the VCR Plus+ Programming System40-41
Playing Options
Real-Time Counter Memory
Repeat Play
A-B Repeat Play
Playback Options
Additional Features
Blue Background
SmartLock
Sleep Timer
Wake Up Timer
Closed Caption
Volume Bar/Smart Sound
Automatic Operation Features
SmartPicture/FM Radio
Remote Locator
Reminder
Index Search
Information You May Need
Specifications
Glossary
Helpful Hints
Limited Warranty
Index
Accessories

Your TV/VCR can find your remote control for you. When you press the POWER button on the TV/VCR to turn on the TV/VCR, your remote control beeps and LOCATING REMOTE appears on the screen. The remote control will beep for about 30 seconds. Or, press any button on the remote control to stop the beeping.

If another remote control beeps...

The TV/VCR may find other remote controls. If this occurs, you can program the TV/VCR to find only its remote control. Follow the steps below.

Press the COMBI button, then press the MENU button.

2

Press the PLAY/▲ button or the STOP/▼ button to select PRIM. SETUP, then press the F.FWD/► button.

3

Press the PLAY/▲ button or the STOP/▼ button to select REMOTE LOCATOR, then press the F.FWD/▶ button.

PRESS MUTE THEN PAUSE KEY

TO CHANGE CODE FROM 4

TO END PRESS EXIT

4

Press the MUTE button, then press the PAUSE/STILL button.

YOUR REMOTE LOCATOR CODE IS 4

PRESS ANY DIGIT TO CHANGE CODE

TO END PRESS EXIT

5

Press one Number button (0 - 9) to enter a single-digit code for your remote control. Your remote control will beep briefly.

YOUR REMOTE LOCATOR CODE HAS BEEN CHANGED


NEW CODE IS 3

TO END PRESS EXIT

6

Press the STATUS/EXIT button.

If another remote control beeps ...



This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Helpful Hint

 The volume will be delayed while the LOCATING REMOTE message appears on the screen. Press the STATUS/EXIT button to remove the message and restore the volume.

62 Specifications

General CRT: 13-inch in line gun (CCB134) 19-inch in line gun (CCB194) Television system: NTSC-M Closed caption system: Section 15.119, FCC (Federal Communications Commission) Standard Video Heads: Four heads Tape width: 1/2 inch (12.65 mm) Tape speed SP: 33.35 mm/sec. LP: 16.67 mm/sec. SLP: 11.12 mm/sec. Operating Temperature: 41 $^{\circ}$ F (5 $^{\circ}$ C) to 104 $^{\circ}$ F (40 $^{\circ}$ C) Relative Humidity: 10% to 75% Power requirement: AC 120V, 60Hz Power consumption: 65W (CCB134) 90W (CCB194) Sound output: IW Dimensions: 15-3/4" (H) x 15-3/16" (W) x 14-13/16" (D) (CCB134) 400mm × 386mm × 377mm 19-11/16" (H) x 19-7/16" (W) x 18-5/16" (D) (CCB194) 500mm x 494mm x 465mm Weight: 24.3 lbs (11.0 kg) (CCB134)

Tuner Broadcast Channels

Weight: 44.1 lbs (20.0 kg) (CCB194)

VHF 2-13, UHF 14-69

Cable TV Channels

1-125

FM Radio Channels

88.0 ~ 108.0 MHz

Terminals

Antenna In: VHF/UHF 75 ohms unbalanced

Video In: RCA connector Audio In: RCA connector Earphone: 3.5 mm CES


Electrical Specifications

Video input level: 0.5~2.0Vp-p Audio input level: -10dBv Video S/N ratio SP: More than 42dBµ Audio S/N ratio SP: More than 38dB

Designs and specifications are subject to change without notice and without our legal obligation.

SUPPLIED ACCESSORIES

The following items are supplied with your TV/VCR; they are provided to help you use or set up your TV/VCR.




OPTIONAL ACCESSORIES

The following additional items are not provided with your TV/VCR, but they are designed for use with your new TV/VCR. To order these optional accessories, contact us at:


Philips Parts & Accessories Marketing Department 401 East Old Andrew Johnson Highway P.O. Box 555 Jefferson City, TN 37760 1-800-851-8885.







Color-coded for easy connection





This owner's manual is made of recycled paper.



As an ENERGY STAR® Partner, Philips Consumer Electronics Company has determined that this product meets the ENERGY STAR® guidelines for energy efficiency. ENERGY STAR® is a U.S. registered mark.

Printed In Malaysia 0EMN0???? / T5111UM * * * * *