Front Side(Outside)

Color is temporary.

Rear Side(Outside)

Color is temporary.

Top Side(Outside)

Bottom Side(Outside)

Right Side(Outside)

VOL   HOLD   microSD

Left Side(Outside)

Color is temporary.