

SONY



WALKMAN®

NW-A55HN/A56HN


4-740-518-21(1)
©2018 Sony Corporation
Printed in Malaysia




1

English
简体中文
繁體中文






DD/MM/YYYY







2



3







i




http://rd1.sony.net/help/dmp/nwa50/h_ww/




?

Windows

 **Music Center for PC**
<http://www.sony.net/smc4pc/>

Mac

 **Content Transfer for Mac**
<http://www.sony.net/ct-mac/>