

SRS-XB402M & SRS-XB402G operation manual

By tonly

目录

1. Input key.....	2
1.1 Single key.....	2
1.1.1 Multi Function Key operation for XBH3.....	3
1.2 Double Key.....	3
2. Boot up.....	4
2.1 insert adapter.....	4
2.2 insert USB.....	4
2.3 press the power key.....	5
3. configure network.....	6
4. login to amazon.....	10
5. use USB to upgrade software.....	15

1. Input key

Industrial Design outline view
SONY

No.		No.	
①	Power Button	⑦	Power Indicator
②	Mic Control Button	⑧	Mic Mute Indicator
③	Multi Function Button	⑨	Bluetooth Indicator
④	Volume "-" Button	⑩	Link Indicator
⑤	Volume "+" Button	⑪	Live Indicator
⑥	Live Button		

1.1 Single key

key name	Function
Power/ Bluetooth Pairing	Short press : Turns the system on/off
	Long press : BT pairing
Volume-	Adjusts the volume.
Volume+	Adjusts the volume.
MIC	Short press: MIC Muting ON/OFF
	Long press(7sec): Restart (Hardware Reset)
Multi Function	See below
Light/Battery	Short press: Lighting Pattern Change (include Light off)
	Long press: Voice guidance
LIVE	Short press: LIVE SOUND on/off (LIVE SOUND <=> EXTRA BASS)
	Long press: STANDARD on/off (STANDARD <=> EXTRA BASS)

1.1.1 Multi Function Key operation for XBH3

	Function	Set Operation	Status/Condition	Operation(press)
1	Play, Pause,	Play	Pause	Short
2	AMS	Pause	Play	Short
3		AMS+	Play/Pause	Short x 2
4		AMS-	Play/Pause	Short x 3
5	Hot Word	Voice Control		Long(2sec)
6	Alarm/Timer	Alarm/Timer Ringing Stop	During Alarm/Timer Ringing	Short

1.2 Double Key

Key Name			Operation
[Volume-]	+	[Power/Bluetooth Pairing]	Factory Data Reset(初期化)
[Volume+]	+	[Power/Bluetooth Pairing]	BT Codec Change(SBC⇔AAC)
[LIVE]	+	[Light/Battery]	WiFi 5G ON/OFF

2. Boot up

Take out the machine from box, there are three ways to turn it on,


2.1 insert adapter




2.2 insert USB



2.3 press the power key




When the line light is on, the boot is successful.




3. configure network


a) Turn on your phone's wifi and bluetooth.



b) Open the music center app





c) Select the device




d) Confirm the WiFi connection, click ok to connect, and then wait about 2 minutes






e) Rename your device name, click OK, wait a few seconds,




f) Set complete, click DONE




4. login to amazon


a) Select your device




b) click Settings




c) Click Amazon Alexa




d) Click Initial Setup




e) Click NEXT




f) Choose language , and click NEXT



g) click NEXT to Connect your Amazon account



h) Enter your account number and password, click allow, and wait 10 seconds



i) Login successfully, click YES,WORK WELL, click DONE ,Network configuration successful





5. use USB to upgrade software

a) Prepare a USB flash disk and an OTG transmission line.



b) Copy XB402M_A.UPG files into the USB flash drives.

c) Use OTG transmission line to link the machine to USB flash disk.



d) Press the power key to boot up.



e) After the boot is completed, press the live key, one of the top indicatie lights will start flashing and the upgrade will start.



f) Wait a few minutes, the second lights in turn flashing blue, and then the machine automatically restart.



g) Then the third and fourth lights flashed blue. the machine restarts automatically and the upgrade is successful

