
Label Location WW46442



the rear side of the equipment

The label is assured not remove in the life of the equipment