




BSport

Quick Reference Guide

FCC ID:ALE12005

www.jabees.com

Jabees BSport is a V4.0 Bluetooth Stereo Sport Headset with A2DP, Multipoint and Battery meter on iOS devices.



Overview of BSport:

Left side

- (1) Earhook
- (2) Volume down / Next song
- (3) Volume up / Previous song
- (4) MF Button (Multifunction Button)
- (5) Speaker

Right side

- (6) Microphone 1
- (7) LED light
- (8) Microphone 2
- (9) On / Off switch
- (10) Charging contact (MicroUSB)

CHARGING THE BATTERY


1. Plug the USB charging cable into the headset.
2. Plug the other end of the USB charging cable into the charger with USB port or PC.
3. The red indicator on the headset will be on.
4. When the battery is fully charged, the red indicator will turn off and the blue indicator will turn on.

The charging takes approximately 2 hours.

WHEN THE BATTERY IS LOW

The red indicator light will flash when the battery is low. At the same time, you can hear the voice prompt 'Battery is low'. At this time, please charge your headset.

Battery meter on iPhone and other iOS devices.



Important

- For first time use, please charge the headset fully before using.
- You must recharge the headset if it has been not used for more than 12 months.
- Make sure that your headset is fully charged for at least 4 hours before initial use.

MULTIFUNCTIONAL BUTTON

Pairing, Answer / End / Reject / Transfer calls, Voice dialing, Redial, Play/Pause music.

TURNING HEADSET ON / OFF

To turn the headset on:

Slide down the On / Off switch, the blue LED light flashes with voice prompt. The headset is now turned on.

To turn the headset off:

Slide up the On / Off switch, the red LED light flashes with voice prompt. The headset is now turned off.

PAIRING THE HEADSET

You are required to pair the headset with your mobile phone once before using it.

1. Turn on the BSport, the LED light flashes in blue and red alternately to go into pairing mode automatically in about 6 seconds. If there is no other previously paired / connected devices in the range.
2. Activate Bluetooth on your mobile phone.

3. Set your phone to discover 'BSport' and follow the instruction.

4. If your phone asks for passkey or PIN-code, confirm with '0000' (4 zero).

5. When the phone and BSport are paired and connected, you will hear the voice prompt.

Note:

1. If BSport is not in pairing mode, your mobile phone won't find the headset. Please set the headset into pairing mode before making your mobile phone search for BSport. You can manually turn the headset into pairing mode by press and hold the MF Button for 2 seconds when the headset is on.
2. If no pairing is possible for a period of time (approximately 2 minutes), the headset will automatically leave pairing mode and go to the idle mode, the blue indicator change to red and flashes.

PAIRING THE HEADSET WITH THE SECOND MOBILE PHONE

BSport supports Multipoint Technology, which means that BSport can be paired and connected with two Bluetooth-enabled mobile phones and use at the same time.

1. Pair and connect BSport with the first mobile phone. (Please refer to the 'PAIRING THE HEADSET' .)

2. Turn off BSport.

3. Turn off the Bluetooth function of the first mobile phone.

4. Turn on BSport and it will go into pairing mode automatically when there is not paired / connected devices in the range.

5. Pairing BSport with the second mobile phone. Turn off BSport once the connection completed.

6. Re-turn on BSport, it will be connected automatically with two mobile phones.

Important: If you need to pair and connect BSport with only one mobile phone, please turn off the Multipoint feature of BSport to avoid the possible audio disruption at the beginning of the music playing, the audio disruption will last for around 20 seconds.

TURN ON THE MULTIPOINT FEATURE

When the headset is on and not connected with any device, short press the V+ and V- at the same time to turn on the multipoint feature.

TURN OFF THE MULTIPOINT FEATURE

When the headset is on and not connected with any device, press and hold the V+ and V- at the same time for 3 seconds to turn off the multipoint feature.

MAKING CALLS

Once the headset is successfully paired and connected with your mobile phone, you can use it to make and receive calls. The headset can be used with voice dialing if your mobile phone supports this feature. Please consult your mobile phone's manual for more information.

1. Using voice dialing:

Double clicks the MF Button, wait for a voice prompt and say the name of the person you want to call.

2. Using the phone keys to make a call:

Enter and dial the number on the mobile phone as you normally do. Once the call has been set up, the sound will be transmitted to your headset automatically.

3. Redial:

Press and hold the MF Button for 2 seconds to redial the last number you called.

ANSWERING / ENDING / REJECTING CALLS

When the headset is turned on and there is an incoming call, you will hear a musical tone.

-Press the MF Button once to answer the call.

-Press the MF Button once to end the call.

-Long press the MF Button for 2 seconds to reject the call.

CALLER ID READING

BSport supports reading the caller's phone number when incoming call.

PUT THE CALL ON HOLD

In call wait state:

Press and hold the MF Button for 2 seconds to put the current call on hold and accept the call waiting.

Press and hold the MF Button for 2 seconds to resume to the first call. Short press the MF Button to end the current call and then transfer to the other call automatically.

TRANSFERRING CALLS

To transfer a call to the mobile phone and back:

During both incoming call and outgoing call state, you can short press the MF Button twice to transfer the call to the mobile phone. If you want to transfer the call back to the headset, short press the MF Button twice again. Some mobile phones may require more confirmation.

ADJUST THE VOLUME

Volume up: Long press V+. You will hear the voice prompt when reaches the highest volume.

Volume down: Long press V-. You will hear the voice prompt when reaches the lowest volume.

MUTE AND UNMUTE

During the call state, short press V+ and V- at the same time to mute, and vice versa.

PLAY AND PAUSE MUSIC

Short press the MF Button to play or pause the music.

NEXT AND PREVIOUS SONG

Short press the V+ to go to previous song.

Short press the V- to go to next song.

CONNECTING WITH A PC OR PDA

You are allowed to connect the headset with a Bluetooth-enabled PC or PDA. Please refer to the user manual of your Bluetooth. Enabled PC or PDA for setup information.

FACTORY RESET

To factory reset the headset, you will have to make sure BSport is not connected with any Bluetooth-enabled device firstly. Then press and hold the MF Button for around 5 seconds, the blue and red LED will be on at the same time for around 2 seconds with 2 beeps. This means that the factory reset is successful.

GUARANTEE

Jabees is a registered trademark of FreeTek International Co., Ltd. Other brands and product names are trademarks of their respective owners. Jabees warrants this product against all defects in material and workmanship for a period of twelve (12) months from the date of original purchase of the product. The conditions of this guarantee and the extent of responsibility of Jabees under this guarantee can be read in the Warranty Card.

WARNING

Permanent hearing loss may result from long-term exposure to sound at high volumes. Use as low volume as possible and avoid prolonged use of the earphone at excessive sound pressure levels. Please read the safety guidelines below prior to using the safety guidelines below prior to using this earphone.

(Prior to using this product follow these steps)

1. Before putting on the earphone, turn the volume control to its lowest level.

2. Put the earphone on, and then slowly adjust the volume control to a comfortable level.

(During the use of this product)

1. Keep the volume at the lowest level as possible.
2. If increased volume is necessary, adjust the volume control slowly.
3. If you experience discomfort or ringing in your ears, immediately discontinue using the earphone. With continued use at high volume, your ears may become accustomed to the sound level, which may result in permanent damage to your hearing without any noticeable discomfort.

SAFETY INFORMATION!

1. If you have a cardiac pacemaker or other electronic medical equipment, you should consult your physician before using this product.

2. This product contains small parts that may be hazardous to children. Keep out of the reach of children. The bags themselves or the many small parts they contain may cause choking if ingested.

3. Never attempt to disassemble the product yourself, or push other objects into this product, as this may cause short circuit, which led to the fire or get an electric shock.

4. None of the components can be replaced or repaired by users. Only authorized dealer or service center may open the product.

5. If any parts of your product require replacement for any reason, including normal wear and rear or breakage, please contact your dealer.

6. If the product overheats, has been dropped or damaged or has been dropped in a liquid, discontinue use.

REMEMBER:

Be sure to ensure safe driving, avoid distractions and follow local laws.

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.