


Jabees JB901M

FCC ID:ALEJB901M

Quick Reference Guide

www.freetekic.com

Connection Diagram



Technical Specification

Bluetooth® Specification : 2.1+EDR
Bluetooth® Profile: A2DP AVRCP
RF Range: 10m
Frequency Response: 100Hz-20KHz
Loudspeaker Output: 3W
Signal-To-Noise: \geq 75dB
Distortion: \leq 1.0%
Playback Time: 8hours
Charging Time: 3 to 4 hours
Dimension: 80 x 80 x 42 mm
Weight: 120g

Introduction

Congratulations, and thank you for choosing the JB901M Bluetooth® Wireless Speaker . This manual will help you operate the Bluetooth® Wireless Speaker, but you should first familiarize yourself with the Bluetooth® functionality of your mobile phone or other devices before using the Bluetooth® Wireless Speaker JB901M .

Safety Rules

- (1) Please follow the rules depicted in this manual closely to ensure your safety. Before using this Bluetooth® speaker, we would strongly encourage you to read through this user manual.
- (2) Be more wary of any edges, uneven surfaces, metal parts, accessories and its packaging so as to prevent any possible injury or damage.
- (3) Do not modify, repair or dismantle this Bluetooth® Speaker, Doing so may result in fires, electric shocks, complete breakdown of this Bluetooth® speaker, etc. All of which, are not covered under warranty.

- (4) Do not use any diluents or volatile liquid to clean the Bluetooth® speaker.
- (5) Do not use the Bluetooth® speaker in a hazardous location.

Package includes



1xJB901M



1xUSB charger



1xlanyard



1x user manual

General Functions

Turn on

Press the "⏮" button for 3 seconds when the device is off
(Blue LED slowly flashes and a tone voice beep).

Enter the pairing mode

Press the "⏮" button and hold on for 6 seconds.
(Blue LED and Red LED quickly flash alternately with two beep tone voice).

Pairing

You should use a Bluetooth® function mobile phone or other Bluetooth® Master Device and to perform pairing action (detail refer to the chapter about pairing).

Play/pause

Press "⏮" to play when the device is pausing and press "⏮" to pause when the device is playing.

Previous/Volume up

Short press "⏮" is for volume up and long press "⏮" is for previous music.

Next/Volume down

Short press "⏭" is for volume down and long press "⏭" is for next music.

Turn off

Press the "⏮" button for 3 seconds when the device is on.
(a tone voice beep and all LED is off)

Low battery warning

The LED flash

Charging

Plug the charger to "⏻" port of the device.(Red LED is on)

Pairing JB901M to Mobile phone or other device

To use your Bluetooth® speaker JB901M, you must first pair your speaker JB901M a phone or a computer. Once your Bluetooth® speaker is paired to a specific mobile phone, they will remain paired and automatically recognize each other whenever they are within range.

Pairing JB901M to a phone and Entertainment:

- Turn on your phone and ensure its Bluetooth® function is activated
- Turn on the JB901M go to the pairing mode.
- Search your Bluetooth® devices on your phone by following the phone's instructions. Refer to your phone's user manual for more information.
- After a few second the phone will list the "JB901M" as a discover device. Select it and follow your phone instruction to select this pairing.
- Then your phone will request a passkey or PIN, enter 0000 as your PIN or passkey.
- Your phone will confirm the pairing, and then press Yes/Ok.

- Finally, select to connect with JB901M form your phone.

- You can play music; watch TV/movie and play game with your phone, then you can hear all the sound or music form the JB901M. Also you can control the player by operating the JB901M. Example, Volume up and next music.

Pairing JB901M to a computer and Entertainment:

- If there is no Bluetooth® function supported by your computer, a Bluetooth® adapter is necessary. Fix the adapter with your computer and ensure its Bluetooth® function is activated.
- Turn on the JB901M to go to the pairing mode.
- Open the Bluetooth® software (such as Blue Soleil) installed on your computer, and selects "Search your Bluetooth® devices" function. Refer to user manual of the Bluetooth® software for more information.
- After a few second the "JB901M" will list in Bluetooth® software of your computer as a discover device. Select this icon and click right button of mouse to select "pairing" item,

then select " connect with audio device" with same operation.

- Open your media player to play music, watch TV/movie and play game, then all the sound will be playback on your JB901M.

Charging your JB901M

The JB901M is convenient to connect to AC charger or a USB charger with Mini DC 2.0 port marked with "⏻" . Make sure that your JB901M is fully charged for at least 6 hours before initial use. Insert one terminal of your charger to AC main or USB port of PC and other terminal to DC 2.0 jack "⏻" . While charging, the LED of JB901M is in solid red. When charging is completed, the LED turns off.

Warning:

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

IMPORTANT REGULATORY INFORMATION

This device complies with Part 15 of the FCC Rules: Operation is subject to the following two conditions:

1. This device may not cause harmful interference and
2. This device must accept any interference that is received, including any interference that may cause undesired operation.