

Digital Security Code Information

=====

262144 Digital Security Code

This cordless telephone system automatically selects a different security code from 262144 possible discrete digital codes each time the cordless telephone is used.

Furthermore, the security code can be changed randomly by pressing 'find handset'