


BOTTOM COVER




FRONT BACK SIDE




Remove FRONT PANEL



FRONT PANEL BACK SIDE




MAIN PCB TOP



Remove HEATSINK



Remove SHIELD CASE



PR-481ZR DIP

12

MAIN13	1	2	3	4
NV	1	2	3	4
SpH	1	2	3	4
DM	1	2	3	4


94V-0 DS-206

TX METER
5 METER


Remove KNOB



Remove FRONT CASE BACK SIDE




Remove FRONT CASE FRONT SIDE



TOP OPEN



TOP VIEW PCB



BOTTOM OPEN



BOTTOM PCB

