

IBM Japan Ltd. 1623-14, Shimotsuruma, Yamato-shi Kanagawa-ken 242-8502, Japan August 22, 2001

To whom this may concern

OET Requested Information

FCC ID : ANOSY3W26629DX

Applicant: International Business Machines Corporation

Correspondence Reference Number: 20263
731 Confirmation Number: EA101218
Original Requested Date: August 17, 2001

Subject:

Please modify the RF safety statement in the manual to indicate that when another transmitter that is not approved to be used with your device, all approved transmitters must be turned off and also tell the user that they must follow the RF Safety instructions for that transmitter.

Answer: Please find the attached update of users manual.

Sincerely, August 22, 2001

J. Murota

Toshiya Murota EMC Engineering

Yamato Laboratory, IBM Japan Ltd.

RF Exposure info. in User's manual

Wireless Regulatory information

The ThinkPad X22 must be installed and used in strict accordance with the instructions as described hereafter. This product complies with the following radio frequency and safety standards.

USA - Federal Communications Commission (FCC)


This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- 1. This device may not cause harmful interference, and
- this device must accept any interference received, including interference that may cause undesired operation.

The FCC RF Safety Requirement

The radiated output power of Wireless LAN Mini-PCI Adapter is far below the FCC radio frequency exposure limits. Nevertheless, the ThinkPad X22 shall be used in such a manner that the potential for human contact during normal operation is minimized as follows:

 CAUTION: To comply with FCC RF exposure compliance requirements, a separation distance of at least 20 cm (8 inches) must be maintained between the antenna of this device and all persons.



- Please make sure of the following, when you will use a Bluetooth option or wireless PCMCIA card in your ThinkPad.
 - 1. Please visit the IBM site at www.ibm.com/pc/support, and check the RF power limit allowed for the wireless options or confirm the updated list of RF devices that have been approved to cooperate with the integrated wireless feature.
 - 2. When you use any other wireless option that is not introduced in the IBM site or exceeds the power limit, all other wireless features in your ThinkPad are required to turn off.
 - 3. Please be careful to follow the RF Safety instructions of wireless option devices that should be indicated in each users manual.