

9. SYSTEM TEST CONFIGURATION

The EUT was configured for testing in a typical fashion (as a customer would normally use it). Push the power button to second position to activate continuous transmission. Push-to-Transmit switch is held in transmit position using electrician's (PVC) tape for transmit mode. The tape is removed for receive mode. Please refer to the following photograph for actual setup.



Radiated Open Site Test Set-up