

9. SYSTEM TEST CONFIGURATION

The EUT was configured for testing in a typical fashion (as a customer would normally use it). Push-to-Transmit switch is held in transmit position using electrician's (PVC) tape for transmit mode. The tape is removed for receive mode. Please refer to the following photograph for actual setup.

