

QUICK START GUIDE



CHARGE 4




WHAT'S IN THE BOX





BLUETOOTH PAIRING




PLAY



CONNECT+




CHARGE



To preserve battery lifespan, fully charge at least once every 45 days.

~~RECHARGE~~



WATERPROOF IPX7

30 MINS



1M

Ensure the cap is well sealed before exposing to liquids.

WARNING!

