


1.1 Product Under Test Photo

Note: Both No5802 and No5805 size dimension are the same. The Bluetooth location for both units are also the same.



The USB/Serial Interface is used to communicate/control the RF module. This is installed temporarily.

Figure 1: Photo of EUT, model No5805 (Front)

Bluetooth RF module location.




Figure 2: Photo of Bluetooth location, zoomed in (Front)



Figure 3: Photo of EUT, model No5805 (Left)



Figure 4: Photo of EUT, model No5805 (Right)



Figure 5: Photo of EUT, model No5805 (Rear)



Figure 6: Photo of EUT, model No5802 (Front)



Figure 7: Photo of EUT, model No5802 (Left)



Figure 8: Photo of EUT, model No5802 (Right)



Figure 9: Photo of EUT, model No5802 (Top)



Figure 10: Photo of EUT, model No5802 (Rear)

Label location