

Home position

The display is home position.



In the desktop window,
slide right or left on
the touch panel.



STEP1

Tap the “設定(=Settings)” icon
(red frame part)



STEP2

Tap “端末情報 (=About phone)”



The display after the STEP1
and scroll down.



The display after the STEP2
and scroll down.

STEP3

Tap “認証 (=Authentication)”

