

Figure 23
Cover Removed, Internal View, M/N LM-700A



Figure 24
Internal View, M/N LM-700A




Figure 25
Internal View (Speaker), M/N LM-700A




Figure 26
Internal View, M/N LM-700A




Figure 27
LCD USB DC-Jack Board (Component Side), M/N LM-700A



Figure 28
LCD USB DC-Jack Board (Foil Side), M/N LM-700A




Figure 29
Power Board (Component Side), M/N LM-700A



Figure 30
Power Board (Foil Side), M/N LM-700A




Figure 31
LCD Audio Board (Component Side), M/N LM-700A



Figure 32
LCD Audio Board (Foil Side), M/N LM-700A



Figure 33
Removed Back Cover, Internal View, M/N LM-700A




Figure 34
Internal View, M/N LM-700A




Figure 35
Internal View, M/N LM-700A




Figure 36
Internal View, M/N LM-700A



Figure 37
Main Board (Component Side), M/N LM-700A



Figure 38
Main Board (Foil Side), M/N LM-700A




Figure 39
Inverter Board (Component Side), M/N LM-700A



Figure 40
Inverter Board (Foil Side), M/N LM-700A




Figure 41
Internal View, M/N LM-700A




Figure 42
Function Adjustment Board (Component Side), M/N LM-700A



Figure 43
Function Adjustment Board (Foil Side), M/N LM-700A




Figure 44
Internal View of LCD Panel, M/N LM-700A



Figure 45
Internal View of LCD Panel, M/N LM-700A




Figure 46
Internal View of LCD Panel, M/N LM-700A




Figure 47
Control Board (Component Side) of LCD Panel, M/N LM-700A




Figure 48
Control Board (Foil Side) of LCD Panel, M/N LM-700A

