


## **EXHIBIT C - EUT INTERNAL PHOTOGRAPHS**


---

**Model: ODM21012**


**EUT – Front Cover Off view**




**EUT – Screen Board Top view**




**EUT – Screen Board Bottom view**




**EUT – Screen Top view**




**EUT – Screen Bottom view**




**EUT – Back Cover Off view**



**EUT – FM Antenna view**




**EUT – Main Board Top view**







**EUT – Main Board Bottom view**



**EUT – Button Board Top view**



**EUT – Button Board Bottom view**



**EUT – DVD Top view**



**EUT – DVD Bottom view**



**Model: ODM30901**


**EUT – Front Uncover view**



**EUT – Screen Board Top view**




**EUT – Screen Board Bottom With Mylar view**







**EUT – Screen Board Bottom Without Mylar view**




**EUT – Screen Top view**




**EUT – Screen Bottom view**




**EUT – Back Cover Off view**




**EUT – FM Antenna view**




**EUT – Main Board Top view**



**EUT – Main Board Bottom view**




**EUT – Button Board Top view**





**EUT – Button Board Bottom view**



**EUT – DVD Top view**



**EUT – DVD Bottom view**

