

# Front Bothside Print Back

## Quick Start Guide

### i111BT

#### Bluetooth Stereo Splitter with Individual Volume Control and Hands-Free Function

Répartiteur stéréo Bluetooth avec commande de volume individuelle et fonction main libre

Torneiro de áudio Bluetooth com controle de volume individual e função mãos livres

Bluetooth-Handsfree mit individueller Lautstärke

### WHAT'S INCLUDED

iluv  
Main Unit  
Micro USB Charging Cable  
3.5mm audio jack  
Bluetooth Receiver  
Spare Parts (Screw)

### PHONE CALLS

Answer the call (Press the **Call** button)  
1. When you receive an incoming call you will hear ringing.  
2. Click **Call** button to answer the call.  
3. Click **Call** button again to answer hang up.  
4. Turn the volume wheel to adjust volume.  
Decline the call (Press the **Decline** button)  
5. Press **Decline** button when you receive an incoming call.  
6. Press **Decline** button when you are in a call.  
7. Press **Call** button for voice control mode.  
8. Press **Call** button for voice control mode.

### VOICE CONTROL

Press **Call** button for voice control mode.  
9. Press **Call** button for voice control mode.  
10. Press **Call** button for voice control mode.  
11. Press **Call** button for voice control mode.

### POWER ON/OFF

1. Slide the power switch to turn on.  
2. i111BT will automatically search for the last device paired.  
3. Turn on Bluetooth on your mobile device.  
4. Go to settings.  
5. Turn on Bluetooth on your mobile device.  
6. Scan for and select "i111BT".  
7. You want to pair with another device.  
8. Unpair i111BT from currently paired mobile device.  
9. Follow the same pairing guideline above.

### LED INDICATION

OFF - Power Off  
Blinking Blue - Bluetooth searching  
Solid Red - Charging  
Red - Fully charged  
Blinking Red - Low Battery

### PLAY MUSIC

1. Once paired, open music app.  
2. Click **Play** button on i111BT to play.  
3. Click **Play** button on i111BT to pause.  
4. Turn the volume wheel to adjust volume.  
5. Press **Next** button to select next track.  
6. Press **Previous** button to move to the beginning of the track.  
7. Press **Play/Pause** button to select play/pause.

### LIMITED WARRANTY

1. This product is covered by a limited warranty for a period of 12 months from the date of purchase. The warranty is void if the product is used for commercial purposes, is damaged by accident, fire, flood, or other external causes, or if it is not used in accordance with the instructions provided in the user manual.

### RETURNING YOUR PRODUCT

1. The product must be returned to the retailer from whom it was purchased, or to the manufacturer's authorized service center. The product must be in its original packaging and in good working order.

### EXCLUSIONS

1. This warranty does not cover the following items:  
- Damage caused by accident, fire, flood, or other external causes.  
- Damage caused by misuse, abuse, or neglect.  
- Damage caused by unauthorized repairs or modifications.  
- Damage caused by use of non-genuine accessories.

### OPTIMIZING WARRANTY SERVICE

1. To ensure the best possible service, please contact the retailer or the manufacturer's authorized service center before returning the product. They will provide you with the necessary information and instructions.

### CONTACT INFORMATION

1. For more information, please contact the retailer or the manufacturer's authorized service center. You can also visit our website for more details.

### WHAT'S INCLUDED

iluv  
Main Unit  
Micro USB Charging Cable  
3.5mm audio jack  
Bluetooth Receiver  
Spare Parts (Screw)

### PHONE CALLS

Answer the call (Press the **Call** button)  
1. When you receive an incoming call you will hear ringing.  
2. Click **Call** button to answer the call.  
3. Click **Call** button again to answer hang up.  
4. Turn the volume wheel to adjust volume.  
Decline the call (Press the **Decline** button)  
5. Press **Decline** button when you receive an incoming call.  
6. Press **Decline** button when you are in a call.  
7. Press **Call** button for voice control mode.  
8. Press **Call** button for voice control mode.

### VOICE CONTROL

Press **Call** button for voice control mode.  
9. Press **Call** button for voice control mode.  
10. Press **Call** button for voice control mode.  
11. Press **Call** button for voice control mode.

### POWER ON/OFF

1. Slide the power switch to turn on.  
2. i111BT will automatically search for the last device paired.  
3. Turn on Bluetooth on your mobile device.  
4. Go to settings.  
5. Turn on Bluetooth on your mobile device.  
6. Scan for and select "i111BT".  
7. You want to pair with another device.  
8. Unpair i111BT from currently paired mobile device.  
9. Follow the same pairing guideline above.

### LED INDICATION

OFF - Power Off  
Blinking Blue - Bluetooth searching  
Solid Red - Charging  
Red - Fully charged  
Blinking Red - Low Battery

### PLAY MUSIC

1. Once paired, open music app.  
2. Click **Play** button on i111BT to play.  
3. Click **Play** button on i111BT to pause.  
4. Turn the volume wheel to adjust volume.  
5. Press **Next** button to select next track.  
6. Press **Previous** button to move to the beginning of the track.  
7. Press **Play/Pause** button to select play/pause.

### LIMITED WARRANTY

1. This product is covered by a limited warranty for a period of 12 months from the date of purchase. The warranty is void if the product is used for commercial purposes, is damaged by accident, fire, flood, or other external causes, or if it is not used in accordance with the instructions provided in the user manual.

### RETURNING YOUR PRODUCT

1. The product must be returned to the retailer from whom it was purchased, or to the manufacturer's authorized service center. The product must be in its original packaging and in good working order.

### EXCLUSIONS

1. This warranty does not cover the following items:  
- Damage caused by accident, fire, flood, or other external causes.  
- Damage caused by misuse, abuse, or neglect.  
- Damage caused by unauthorized repairs or modifications.  
- Damage caused by use of non-genuine accessories.

### OPTIMIZING WARRANTY SERVICE

1. To ensure the best possible service, please contact the retailer or the manufacturer's authorized service center before returning the product. They will provide you with the necessary information and instructions.

### CONTACT INFORMATION

1. For more information, please contact the retailer or the manufacturer's authorized service center. You can also visit our website for more details.

### WHAT'S INCLUDED

iluv  
Main Unit  
Micro USB Charging Cable  
3.5mm audio jack  
Bluetooth Receiver  
Spare Parts (Screw)

### PHONE CALLS

Answer the call (Press the **Call** button)  
1. When you receive an incoming call you will hear ringing.  
2. Click **Call** button to answer the call.  
3. Click **Call** button again to answer hang up.  
4. Turn the volume wheel to adjust volume.  
Decline the call (Press the **Decline** button)  
5. Press **Decline** button when you receive an incoming call.  
6. Press **Decline** button when you are in a call.  
7. Press **Call** button for voice control mode.  
8. Press **Call** button for voice control mode.

### VOICE CONTROL

Press **Call** button for voice control mode.  
9. Press **Call** button for voice control mode.  
10. Press **Call** button for voice control mode.  
11. Press **Call** button for voice control mode.

### POWER ON/OFF

1. Slide the power switch to turn on.  
2. i111BT will automatically search for the last device paired.  
3. Turn on Bluetooth on your mobile device.  
4. Go to settings.  
5. Turn on Bluetooth on your mobile device.  
6. Scan for and select "i111BT".  
7. You want to pair with another device.  
8. Unpair i111BT from currently paired mobile device.  
9. Follow the same pairing guideline above.

### LED INDICATION

OFF - Power Off  
Blinking Blue - Bluetooth searching  
Solid Red - Charging  
Red - Fully charged  
Blinking Red - Low Battery

### PLAY MUSIC

1. Once paired, open music app.  
2. Click **Play** button on i111BT to play.  
3. Click **Play** button on i111BT to pause.  
4. Turn the volume wheel to adjust volume.  
5. Press **Next** button to select next track.  
6. Press **Previous** button to move to the beginning of the track.  
7. Press **Play/Pause** button to select play/pause.

### LIMITED WARRANTY

1. This product is covered by a limited warranty for a period of 12 months from the date of purchase. The warranty is void if the product is used for commercial purposes, is damaged by accident, fire, flood, or other external causes, or if it is not used in accordance with the instructions provided in the user manual.

### RETURNING YOUR PRODUCT

1. The product must be returned to the retailer from whom it was purchased, or to the manufacturer's authorized service center. The product must be in its original packaging and in good working order.

### EXCLUSIONS

1. This warranty does not cover the following items:  
- Damage caused by accident, fire, flood, or other external causes.  
- Damage caused by misuse, abuse, or neglect.  
- Damage caused by unauthorized repairs or modifications.  
- Damage caused by use of non-genuine accessories.

### OPTIMIZING WARRANTY SERVICE

1. To ensure the best possible service, please contact the retailer or the manufacturer's authorized service center before returning the product. They will provide you with the necessary information and instructions.

### CONTACT INFORMATION

1. For more information, please contact the retailer or the manufacturer's authorized service center. You can also visit our website for more details.

### WHAT'S INCLUDED

iluv  
Main Unit  
Micro USB Charging Cable  
3.5mm audio jack  
Bluetooth Receiver  
Spare Parts (Screw)

### PHONE CALLS

Answer the call (Press the **Call** button)  
1. When you receive an incoming call you will hear ringing.  
2. Click **Call** button to answer the call.  
3. Click **Call** button again to answer hang up.  
4. Turn the volume wheel to adjust volume.  
Decline the call (Press the **Decline** button)  
5. Press **Decline** button when you receive an incoming call.  
6. Press **Decline** button when you are in a call.  
7. Press **Call** button for voice control mode.  
8. Press **Call** button for voice control mode.

### VOICE CONTROL

Press **Call** button for voice control mode.  
9. Press **Call** button for voice control mode.  
10. Press **Call** button for voice control mode.  
11. Press **Call** button for voice control mode.

### POWER ON/OFF

1. Slide the power switch to turn on.  
2. i111BT will automatically search for the last device paired.  
3. Turn on Bluetooth on your mobile device.  
4. Go to settings.  
5. Turn on Bluetooth on your mobile device.  
6. Scan for and select "i111BT".  
7. You want to pair with another device.  
8. Unpair i111BT from currently paired mobile device.  
9. Follow the same pairing guideline above.

### LED INDICATION

OFF - Power Off  
Blinking Blue - Bluetooth searching  
Solid Red - Charging  
Red - Fully charged  
Blinking Red - Low Battery

### PLAY MUSIC

1. Once paired, open music app.  
2. Click **Play** button on i111BT to play.  
3. Click **Play** button on i111BT to pause.  
4. Turn the volume wheel to adjust volume.  
5. Press **Next** button to select next track.  
6. Press **Previous** button to move to the beginning of the track.  
7. Press **Play/Pause** button to select play/pause.

### LIMITED WARRANTY

1. This product is covered by a limited warranty for a period of 12 months from the date of purchase. The warranty is void if the product is used for commercial purposes, is damaged by accident, fire, flood, or other external causes, or if it is not used in accordance with the instructions provided in the user manual.

### RETURNING YOUR PRODUCT

1. The product must be returned to the retailer from whom it was purchased, or to the manufacturer's authorized service center. The product must be in its original packaging and in good working order.

### EXCLUSIONS

1. This warranty does not cover the following items:  
- Damage caused by accident, fire, flood, or other external causes.  
- Damage caused by misuse, abuse, or neglect.  
- Damage caused by unauthorized repairs or modifications.  
- Damage caused by use of non-genuine accessories.

### OPTIMIZING WARRANTY SERVICE

1. To ensure the best possible service, please contact the retailer or the manufacturer's authorized service center before returning the product. They will provide you with the necessary information and instructions.

### CONTACT INFORMATION

1. For more information, please contact the retailer or the manufacturer's authorized service center. You can also visit our website for more details.