

MTR-H5-Label location and design



Figure (1) label located on the bottom of the device




Figure (2) label template