


GTL 1218A USER GUIDE

Wireless Charging Bluetooth Retro Handset



Operation instruction:

Bluetooth Retro Handset:

1. Plug the mini USB plug of the included USB cable into the mini USB jack on the handset base. Connect the USB plug on the other side of the cable to power source (it can be a USB port of a computer or an USB jack of an AC adapter).
2. Put the Bluetooth Retro Handset on the handset base. The Power LED should light. If the LED does not light, check the followings,
 - The plugs of the USB cable are properly connected.
 - Rotate the handset 180 degrees and put it properly on the handset base.
3. The handset will be automatically charged wirelessly. Allow it to be charged for about 3-4 hours before the first use.
4. You need to pair the Bluetooth Retro Handset with your cell phone (Bluetooth pairing is the process of establishing the wireless link between 2 devices). Refer to your cell phone manual for instructions on how to use the Bluetooth pairing function in your phone.
5. Push and hold the button on the Bluetooth Retro Handset. After about 5 seconds, the button will illuminate briefly and the Bluetooth Retro Handset will make a short beep. Continue holding the button for another 3-4 seconds until the blue light of the button starts to blink rapidly. The Bluetooth Retro Handset is now in pairing mode.
6. Follow your phone's instruction manual regarding the Bluetooth portion. This normally involves going to a "Setup", "Connect", "Connection" or "Bluetooth" menu on your cell phone. Select the option to "Look for devices", "Add a device" or "Discover" to initiate the Bluetooth pairing process.
7. Your cell phone will scan for nearby Bluetooth devices and should locate the Bluetooth Retro Handset within 10-20 seconds.
8. When you pair your cell phone with the Bluetooth Retro Handset it will prompt you to enter a PIN number – enter "0000" for this number.
9. The button on the Bluetooth Retro Handset will change from rapid blinking to slow blinking. The Bluetooth Retro Handset is paired with your cell phone.
10. At this point you should be able to place a call using your cell phone (through keypad, phone book, or voice dial) and use the Bluetooth Retro Handset in place of your phone's handset. The Bluetooth Retro Handset functions much like any hands free headset.
11. When there is incoming call, there will be melody on Bluetooth Retro Handset. To answer an incoming call, press the button on the Bluetooth Retro Handset. Press the button again to terminate the call.
12. To turn off the Bluetooth Retro Handset, press and hold the button for about 3 seconds until you hear a short sound and the blue light of the button turns off.

Note:

In very rare cases, if the Bluetooth Retro Handset locks up, put a pinned object such as paper clip through the Reset hole to reset the Bluetooth Retro Handset.

Danger

To reduce the risk of electric shock, burns, fire or injury:

- 1) Do not use while bathing or in a shower.
- 2) Do not place or store unit where it can fall or be pulled into a tub or sink.
- 3) Do not place in, drop or submerge in water or other liquid.
- 4) Do not reach for unit that has fallen into water. Unplug it immediately.
- 5) Care should be taken so that objects do not fall and liquids are not spilled onto the unit.

WARNING

- 1) Close supervision is necessary when this appliance/product is used by or near children or mentally disabled individuals.
- 2) Use this unit only for its intended use as described in this manual.
- 3) Unplug this unit during lightning storms or when unused for long period of time.
- 4) Never drop or insert an object into any opening.
- 5) Protect the power cord from being walked on or pinched, particularly at plug outlets, convenience receptacle and the point where it exits the unit.
- 6) Do not allow cord to touch hot surfaces. Wrap cord loosely around the unit when storing.
- 7) The unit should be situated away from direct sunlight or heat sources such as radiators, electric heaters, heat registers, stoves, or other units (including amplifiers) that produce heat. Avoid placing on top of stereo equipment that radiates heat.
- 8) Never block the air openings of the unit with materials such as clothing, plastic bags or papers, or place it on a soft surface such as a bed or couch, where the air openings may be blocked.
- 9) Do not overload electrical outlet. Use only the power source as indicated.
- 10) Do not carry this unit by cord or use cord as handle.
- 11) Never operate the unit if it has a damaged cord or plug, if it is not working properly, or if it has been dropped or damaged, or dropped into water. If the unit's power supply cord or plug is damaged, do not attempt to fix it yourself.
- 12) To avoid the risk of electric shock, do not disassemble or attempt to repair the unit. Incorrect repair can cause risk of electric shock or injury to persons when unit is used.
- 13) Do not operate in the presence of explosive and/or flammable fumes.
- 14) Never remove the plug from the socket by pulling the power cord.
- 15) Check the voltage indicated on the AC adapter and make sure it corresponds to the local voltage before you connect the adapter to an electrical socket.

- 16) Never use the AC adapter, charging tray or receive case if any of them are damaged in any way.
- 17) Only use the official AC adapter (supplied together with the Greentech Power Tray mini).
- 18) Do not use the charging tray outdoors or near heat surfaces.
- 19) If you have a pacemaker or other implanted device, consult your doctor or the manufacturer of the implanted device before using the charging tray.

CAUTION

*TO REDUCE THE RISK OF ELECTRIC SHOCK, DO NOT REMOVE COVER. THERE ARE NO SERVICEABLE PARTS INSIDE.

*TO REDUCE THE RISK OF FIRE OR ELECTRIC SHOCK, DO NOT EXPOSE THIS UNIT TO RAIN OR MOISTURE.



The lightning flash with arrow-head symbol within an equilateral triangle is intended to alert the user to the presence of uninsulated "dangerous voltage" within the unit's enclosure that may be of sufficient magnitude to constitute a risk of electric shock.



The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the unit.

IMPORTANT SAFETY INSTRUCTIONS

All the safety and operating instructions should be read, adhered to and followed before the unit is operated.

SAVE THESE INSTRUCTIONS

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

The device complies with part 15 of the FCC rules. Operation is subject to the following two conditions:
<1> This device may not cause harmful interference,
<2> This device must accept any interference received, including interference that may cause undesired operation.

Model No.: GTL 1218A

DC 5V 0.5A
Made in China

