

EUT Internal Photos

Figure 7
Internal View (Removed Battery Cover)



Figure 8
Internal View (Control Board, Front View)




Figure 9
Internal View (Control Board)




Figure 10
Internal View (Removed ANTs)



Figure 11
Internal View (ANT, Front View)



Figure 12
Internal View (ANT, Back View)



Figure 13
Internal View




Figure 14
Internal View (TB86A-1 Board, Front View)




Figure 15
Internal View (TB86A-1 Board, Back View)




Figure 16
Internal View (LCD Display, Back View)



Figure 17
Internal View




Figure 18
Internal View (TB86A-2 Board, Front View)




Figure 19
Internal View (I TB86A-2 Board, Back View)




Figure 20
Internal View (Main Board, Front View)




Figure 21
Internal View (Main Board, Back View)




Figure 22
Internal View (RF Module)

