

EUT Internal Photos

Figure 6
Internal View (Removed Battery Cover)



Figure 7
Internal View (Removed Cover)



Figure 8
Internal View (Antenna View)



Figure 9
Internal View (Main Board, Front View)



Figure 10
Internal View (Main Board, Back View)




Figure 11
Internal View (Control Board and RF Board)




Figure 12
Internal View (Control Board, Front View)



Figure 13
Internal View (Control Board, Back View)




Figure 14
Internal View (RF Board, Front View)



Figure 15
Internal View (RF Board, Back View)



Figure 16
Internal View (Control Board, Back View)




Figure 17
Internal View (Control Board, Front View)

