

EUT Internal Photos

Figure 6
Internal View (Removed Battery Cover)



Figure 7
Internal View (Removed Cover)



Figure 8
Internal View (Antenna View)




Figure 9
Internal View (Removed Main Board and LCD Panel)




Figure 10
Internal View (LCD Panel, Front View)




Figure 11
Internal View (LCD Panel, Back View)




Figure 12
Internal View (Function Key Board, Front View)




Figure 13
Internal View (Function Key Board, Back View)




Figure 14
Internal View (Main Board, Front View)




Figure 15
Internal View (Removed RF Module)




Figure 16
Internal View (RF Module, Back View)




Figure 17
Internal View (RF Module, Front View)




Figure 18
Internal View (Main Board, Back View)




Figure 19
Internal View (Control Board, Front View)




Figure 20
Internal View (Control Board, Back View)




Figure 21
Internal View (Control Board, Back View)




Figure 22
Internal View (Control Board, Front View)





Figure 23
Internal View (Control Board, Front View)



*Figure 24
Internal View (Control Board, Back View)*

