

EUT Internal Photos

Figure 5  
Internal View (Removed Battery Cover)



Figure 6  
Internal View (Removed Battery Case)




Figure 7  
Internal View (Removed RF ANT)



Figure 8  
Internal View (Removed Covers)




Figure 9  
Internal View (TC11A-A Board)




Figure 10  
Internal View (TC11A-9 Board, Front View)



Figure 11  
Internal View (TC11A-9 Board, Back View)




Figure 12  
Internal View



Figure 13  
Internal View (Display, Front View)



Figure 14  
Internal View (Display, Back View)




Figure 15  
Internal View (RF ANT)




Figure 16  
Internal View




Figure 17  
Internal View (Control Board)




Figure 18  
Internal View (TC11A-5 Board, Front View)




Figure 19  
Internal View (TC11A-5 Board, Back View)



Figure 20  
Internal View (TC11A-6 Board, Front View)






Figure 21  
Internal View (TC11A-6 Board, Back View)




Figure 22  
Internal View (TC11A-2 Board, Front View)




Figure 23  
Internal View (TC11A-2 Board, Back View)




Figure 24  
Internal View (TC11A-1 Board, Front View)




Figure 25  
Internal View (TC11A-1 Board, Back View)




Figure 26  
Internal View (TC11A-1 Board, Removed RF Board)




Figure 27  
Internal View (RF Board, Front View)




Figure 28  
Internal View (RF Board, Back View)

