

EUT Internal Photos

Figure 5  
Internal View (Remove Antenna)



Figure 6  
Internal View (Remove Antenna Cover)



Figure 7  
Internal View (RF Board & Control Board)




Figure 8  
Internal View (RF Board, Front View)






Figure 9  
Internal View (RF Board, Back View)




Figure 10  
Internal View (Control Board, Front View)



Figure 11  
Internal View (Control Board, Back View)



Figure 12  
Internal View (Removed Battery Cover)



Figure 13  
Internal View (Removed Cover)



Figure 14  
Internal View (Control Board, Front View)





Figure 15  
Internal View (Control Board, Back View)



Figure 16  
Internal View (Remove Main Board)



Figure 17  
Internal View (Main Board, Front View)




Figure 18  
Internal View (Main Board, Back View)






Figure 19  
Internal View (Remove Metal Cover)




Figure 20  
Internal View (Control Board, Back View)






Figure 21  
Internal View (Control Board, Front View)




Figure 22  
Internal View (Control Board, Back View)




Figure 23  
Internal View (Control Board, Front View)

