

VX 520 Color D/E CTLS

MPLATERE

Installation Guide

VX 520 Color D/E CTLS Installation Guide © 2012 VeriFone, Inc.

All rights reserved. No part of the contents of this document may be reproduced or transmitted in any form without the written permission of VeriFone, Inc.

The information contained in this document is subject to change without notice. Although VeriFone has attempted to ensure the accuracy of the contents of this document, this document may include errors or omissions. The examples and sample programs are for illustration only and may not be suited for your purpose. You should verify the applicability of any example or sample program before placing the software into productive use. This document, including without limitation the examples and software programs, is supplied "As-Is."

VeriFone, the VeriFone logo, VeriCentre, Verix, and ZonTalk are registered trademarks of VeriFone. Other brand names or trademarks associated with VeriFone's products and services are trademarks of VeriFone, Inc.

All other brand names and trademarks appearing in this manual are the property of their respective holders.

Comments? Please e-mail all comments on this document to your local VeriFone Support Team.

VeriFone, Inc. 2099 Gateway Place, Suite 600 San Jose, CA, 95110 USA

www.verifone.com

VeriFone Part Number DOC252-XXX-EN-A, Revision A.1



CONTENTS

	PREFACE
	Audience.5Organization5Related Documentation5Conventions and Acronyms6Document Conventions.6Acronym Definitions6
CHAPTER 1 Terminal Overview CHAPTER 2	Features and Benefits10Connectivity10Performance10Security10Form Factor10Exceptional Ease of Use11Countertop Performance in a Hand-Over Design11True Multi-Application Capability11
Terminal Setup	Selecting Terminal Location13Ease of Use13Environmental Factors14Electrical Considerations14Unpacking the Shipping Carton14Examining Terminal Features15Front Panel15Connection Ports16Establishing Telephone Line Connections19Installing/Replacing MSAM Cards21Connecting Optional Devices23Optional Device Connections23External Printers Supported25Connecting the Terminal Power Pack26Privacy Shield (Optional)27Using the CTLS Reader28Using the Magnetic Card Reader29Using the Magnetic Card Reader30
CHAPTER 3 Specifications	Power 31 DC Power Pack. 31 Temperature 31 External Dimensions. 31

CHAPTER 4 Maintenance	Clean the Terminal33Terminal Contacts33Smart Card Reader33	
CHAPTER 5 Troubleshooting Guidelines	Blank Display35Terminal Does Not Dial Out36Printer Paper Jam.36Keypad Does Not Respond36Peripheral Device Does Not Work36Transactions Fail To Process.37Printer Does Not Print.38Terminal Display Does not Show Correct or Readable Information38Terminal Does Not Start.38	
CHAPTER 6 VeriFone Service and Support	Return a Terminal for Service.39Accessories and Documentation40Printer Paper.40Supplementary Hardware40VeriFone Cleaning Kit.40Telephone Line Cord40Documentation41INDEX43	

TEMPLATEREV



This guide is your primary source of information for setting up and installing the VX 520 Color D/E CTLS terminal.

Audience This guide is useful for anyone installing and configuring a VX 520 Color D/E CTLS terminal. This manual also provides a basic description of the terminal features.

Organization This guide is organized as follows:

Chapter 1, Terminal Overview. Provides an overview of the VX 520 Color D/E CTLS terminal.

Chapter 2, Terminal Setup. Explains how to set up and install the VX 520 Color D/E CTLS terminal. It tells you how to select a location, establish power and telephone line connections, and how to configure optional peripheral devices.

Chapter 3, Specifications. Discusses power requirements and dimensions of the VX 520 Color D/E CTLS terminal.

Chapter 4, Maintenance. Explains how to maintain your VX 520 Color D/E CTLS terminal.

Chapter 5, Troubleshooting Guidelines. Provides troubleshooting guidelines, should you encounter a problem in terminal installation and configuration.

Chapter 6, VeriFone Service and Support. Provides information on contacting your local VeriFone representative or service provider, and information on how to order accessories or documentation from VeriFone.

Related Documentation

To learn more about the VX 520 Color D/E CTLS terminal, refer to the following set of documents:

VX 520 Color D/E CTLS Certifications and Regulations	VPN DOC252-0xx-EN-A
VX 520 Color D/E CTLS Quick Installation Guide	VPN DOC252-0xx-EN-A
VX 520 Color D/E CTLS Reference Manual	VPN DOC252-0xx-EN-A

Acronyms

Conventions and This section describes the conventions and acronyms used in this guide.

Document Various conventions are used to help you quickly identify special formatting. **Conventions** Table 1 describes these conventions and provides examples of their use.

Table 1 **Document Conventions**

Convention		
Blue	Text in blue indicates terms that are cross referenced.	See Conventions and Acronyms.
Italics	Italic typeface indicates book titles or emphasis.	You <i>must</i> install a roll of thermal- sensitive paper in the printer.
Courier	The courier type face is used while specifying onscreen text, such as text that you would enter at a command prompt, or to provide an URL.	http://www.verifone.com
NOTE	The pencil icon is used to highlight important information.	RS-232-type devices do not work with the PIN pad port.
	The caution symbol indicates possible hardware or software failure, or loss of data.	The terminal is not waterproof or dust proof, and is intended for indoor use only.
WARNING	The lighting symbol is used as a warning when bodily injury might occur.	Due to risk of shock do not use the terminal near water.

Acronym Definitions

Various acronyms are used in place of the full definition. Table 2 presents acronyms and their definitions.

Table 2	Acronym Definitions
Acronym	Definitions
AC	Alternating Current
ATM	Automated Teller Machine
CPU	Central Processing Unit
CTLS	Contactless
DC	Direct Current
EMV	Europay MasterCard and VISA
GPRS	General Packet Radio Service
ITP	Internal Thermal Printer
LCD	Liquid Crystal Display

Table 2	Acronym Definitions (continued)
Acronym	Definitions
LED	Light Emitting Diode
MRA	Merchandise Return Authorization
MSAM	Micromodule-Size Security Access Module
PCI	Payment Card Industry
PED	PIN-Entry Devices
PIN	Personal Identification Number
RAM	Random Access Memory
RJ-11	Registered Jack 11
RJ-45	Registered Jack 45
RS-232	Recommended Standard 232
SAM	Security Access Module
SIM	Subscriber Identity Module
VPN	VeriFone Part Number

£:... 24.2 1 n)

Table O







Terminal Overview

This chapter provides a brief description of the VX 520 Color D/E CTLS terminal:

- The VX 520 Color D/E CTLS is a high performance countertop terminal with enhanced communication options.
- The VX 520 Color D/E CTLS offers several communication options, enhanced display, increased processing power, expanded memory, and two USB peripheral ports.

The VX 520 Color D/E CTLS terminal uses a robust, sleek, and highly functional design.



VeriFone ships variants of the VX 520 terminals for different markets. Your terminal may have a different configuration from the features described in this section.



Figure 1 VX 520 Color D/E CTLS Terminal

Features and Benefits	VX 520 Color D/E CTLS terminals provide the right combination of features and functions. This includes a contactless (CTLS) reader, triple-track magnetic-stripe	
	card reader, landed smart card reader, integrated PIN pad, and a quiet internal thermal printer (ITP).	
Connectivity	USB 2.0 Host port	
	USB 2.0 Device port (Mini USB)	
	RJ-11 port	

- RS-232 port
- Ethernet port



NOTE

The connectivity ports are easily accessible from the underside of the terminal.

VeriFone ships variants of the VX 520 terminals for different markets. Your terminal may have a different configuration from the features described in this section.

Performance • ARM11 (CPU)

- Increased memory (128 MB Flash, 32 MB RAM)
- Colored 240 x 320 LCD display with white backlight
- Fastest encryption/decryption appliance on the market
- Blue backlit keypad

Security • Increased Security (PCI 3.0 to PCI 3.1)

- SDA DDA encryption ready
- Leading ECC Performance Benchmark
- **Form Factor** The VX 520 Color D/E CTLS is ergonomically designed to fit both the traditional countertop and hand-over models.

Exceptional Ease of • The contactless functionality offers a convenient payment option for consumers.

- The bold design is sleek, stylish, and lightweight for conveniently handing the terminal to the consumer for PIN entry or other input.
- A large 15-line by 40-character colored backlit display with backlit keypad, and extra-size menu prompts, simplify training and reduce help desk calls.
- The integrated thermal printer simplifies paper loading and reduces paper jams.
- The triple-track, high-coercivity card reader handles most magnetic stripe cards.

Countertop • Performance in a Hand-Over Design

- The 32-bit processing and multi-tasking capabilities ensures fast processing of payment, payment-related, and value-added applications.
- Exceptional display and printer graphics-handling capabilities that quickly render logos, graphical fonts, and character-based languages.
- The VX 520 Color D/E CTLS series of terminals ensures uncompromising reliability from VeriFone, the worldwide leader in e-payment.

True Multi-Application Capability

- The VX 520 Color D/E CTLS terminal offers 32 MB of random access memory, and 128 MB dynamic memory allocation of the operating system, which supports multiple applications on a single terminal.
- The primary smart card reader and the MSAMs safeguard sensitive financial data and support multiple smart card schemes.
- VX 520 Color D/E CTLS terminals and SoftPay EMV software are certified for EMV Level 1 and Level 2 Type approval for smart card solutions. The Verix V or Vx EMV Library provides development of other EMV-compliant applications.
- The VeriShield security architecture meets published specifications for PCI PED and provides sophisticated file authentication to prevent execution of unauthorized software on VX 520 Color D/E CTLS terminals





Terminal Setup

This chapter describes the terminal setup procedure. You will learn about:

- Selecting Terminal Location
- Unpacking the Shipping Carton
- Examining Terminal Features
- Establishing Telephone Line Connections
- Installing a Paper Roll in the Printer
- Installing/Replacing MSAM Cards
- Connecting Optional Devices
- Connecting the Terminal Power Pack
- Privacy Shield (Optional)
- Using the CTLS Reader
- Using the Smart Card Reader
- Using the Magnetic Card Reader

Selecting Use the following guidelines when selecting a location for your Terminal VX 520 Color D/E CTLS terminal.

Ease of Use • Select a location convenient for both merchant and cardholder.

- Select a flat support surface, such as a countertop or table.
- Select a location near a power outlet and a telephone/modem line connection.
 For safety, do not string the power cord in a walkway or place it across a walkway on the floor.

Environmental Factors	• Do not use the terminal where there is high heat, dust, humidity, moisture, or caustic chemicals or oils.
	• Keep the terminal away from direct sunlight and anything that radiates heat, such as a stove or motor.
	• Do not use the terminal outdoors.
	The terminal is not waterproof or dustproof, and is intended for indoor use only. Any damage to the unit from exposure to rain or dust may void any warranty.
Electrical	Avoid using this product during electrical storms.
Considerations	• Avoid locations near electrical appliances or other devices that cause excessive voltage fluctuations or emit electrical noise (for example, air conditioners, electric motors, neon signs, high-frequency or magnetic security devices, or computer equipment).
	• Do not use the terminal near water or in moist conditions.
Unpacking the Shipping Carton	Open the shipping carton and carefully inspect its contents for possible tampering or shipping damage. The VX 520 Color D/E CTLS terminal is a secure product and any tampering may cause the device to cease to function properly.
To unpack the shipping carton	1 Remove and inspect the following items:Terminal
	Power pack
	Telephone line cord
	Power cord
	2 Remove all plastic wrapping from the terminal and other components.
	3 Remove the clear protective film from the LCD screen.
	Do not use a terminal that has been damaged or tampered with. The VX 520 Color D/E CTLS terminal comes equipped with tamper-evident labels. If a label or component appears damaged, please notify the shipping company and your

- VeriFone representative or service provider immediately.
- 4 Save the shipping carton and packing material for future repacking or moving the terminal.

Examining Before you continue the installation process, notice the features of the VX 520
 Terminal Color D/E CTLS terminal (see Figure 2).
 Features

Figure 2 VX 520 Color D/E CTLS Terminal Features (Front Panel)



VeriFone ships variants of the VX 520 Color D/E CTLS terminals for different markets. Your terminal may have a different configuration from the features described in this section.

Front Panel The front panel includes the following features:

- A **terminal display**, colored LCD screen with white backlight. The screen also acts as the CTLS tapping area for contactless transactions.
- Four types of keys:
 - a A backlit 12-key, telephone-style keypad.
 - **b** Four unlabeled, **programmable function keys** above the keypad.

TERMINAL SETUP Examining Terminal Features

c Three **color-coded function keys** below the keypad (icons at right; from left to right: CANCEL, BACKSPACE/CLEAR, ENTER).



- d A **NAVIGATION key** centered at the top of the keypad for easy access to menu items displayed in the LCD screen.
- A magnetic card reader, built into the right side. The icon at right shows the proper swipe direction, with the stripe down and facing inward, toward the keypad.
- An internal thermal printer.
- A **smart card reader**, built into the front of the terminal. The icon shown at right indicates proper card position and insertion direction.



 Three SAM (security access module) compartments, built into the side of the terminal. The VX 520 Color D/E CTLS terminal contains MSAM cardholders to support multiple stored-value card programs or other merchant card requirements.



VeriFone ships variants of the VX 520 Color D/E CTLS terminal for different markets. Your terminal may have a different configuration. However, the basic processes described in this guide remain the same, regardless of terminal configuration.

Connection Ports Turn the terminal upside down and remove the rear cover to view the connection ports. Notice that the ports are recessed. Different ports provide connections to a communications line, optional peripheral devices, and the power supply.

Figure 3 shows how to open the rear cover of the VX 520 Color D/E CTLS terminals.

Figure 3 Opening the VX 520 Color D/E CTLS Rear Cover

Figure 4 to Figure 5 show the connection ports for the VX 520 Color D/E CTLS terminal.



Figure 5 Additional VX 520 Color D/E CTLS Connection Ports



Do not connect the terminal to the power supply until all the peripherals are attached.

To use the connection ports

The connection ports offer multiple connectivity for the VX 520 Color D/E CTLS terminal. Please refer to the following list of peripheral devices for the connectivity options.

Host USB Port

- PP1000 USB
- V^x810 USB
- VX 820 USB
- Barcode reader
- Biometric reader
- USB flash disk
- USB keyboards

Ethernet Port

• Ethernet cable to router, hub or switch

Client USB Port

- PC
- ECR/Cash register

RJ-11 Port

Telephone line

RS-232 Port

- PP1000
- V^x810
- VX 820
- PC download cable
- Computer
- ECR
- Check reader
- CTLS reader
- Biometric reader
- Barcode reader
- Keyboard

For information on how to attach peripheral devices, see Connecting Optional Devices.

Establishing Telephone Line Connections Connections Connections Connection

Figure 6 VX 520 Color D/E CTLS Direct Telephone Connection



To reduce the risk of fire, use only No. 26AWG or larger UL Listed or CSA Certified Telecommunication Line Cord.

Installing a Paper Roll in the Printer

Before you can process transactions that require a receipt or record, you *must* install paper in the printer.

The VX 520 Color D/E CTLS uses a roll of 40 mm-diameter, single-ply, thermalsensitive paper.

A pink *out-of-paper* indicator line appears on the edge of the paper before the end of the roll. After this line appears, there is enough paper remaining on the roll to conclude at least one transaction.



Poor-quality paper can jam the printer and create excessive paper dust. To order high-quality VeriFone paper, refer to Accessories and Documentation.

Store thermal paper in a dry, dark area. Handle thermal paper carefully: impact, friction, temperature, humidity, and oils affect the color and storage characteristics of the paper.

Never load a roll of paper with folds, wrinkles, tears, or holes at the edges.

TERMINAL SETUP Installing a Paper Roll in the Printer

To install a paper roll **1** Hook your finger under the latch and lift up to swing the paper roll cover open (see Figure 7).

Figure 7 Opening the Printer Cover

- 2 Remove any partial roll of paper in the printer tray by lifting it up.
- 3 Loosen the glued leading edge of the new paper roll or remove the protective strip. Unwind the paper roll past any glue residue.
- 4 Hold the roll so the paper feeds from the *bottom* of the roll.
 - Drop the paper roll into the printer tray.

Figure 8 Loading Paper Roll

6 Pull paper up past the glue residue.

7 Close the paper roll cover by gently pressing directly on the cover until it clicks shut, allowing a small amount of paper past the glue residue to extend outside the printer door. (see Figure 9).



To prevent the paper roll cover from damaging the print roller, always gently press down on the printer dust cover to close it.

Figure 9 Closing Paper Roll Cover

8 Tear the paper off against the serrated metal strip in the printer.



For paper ordering information, refer to Accessories and Documentation.

Installing/ Replacing MSAM Cards

When you first receive your VX 520 Color D/E CTLS terminal, you may need to install one or more MSAM cards or you may need to replace old cards.



Observe standard precautions when handling electrostatically sensitive devices. Electrostatic discharges can damage this equipment. VeriFone recommends using a grounded anti-static wrist strap.

To install or replace MSAMs

- 1 Remove the power cord from the power outlet.
- **2** Place the terminal upside down on a soft, clean surface to protect the display from scratches.

TERMINAL SETUP Installing/Replacing MSAM Cards

3 Press the unlocking button and then lift the rear cover to access the MSAM cardholder panel.

Figure 10 Opening VX 520 Color D/E CTLS Rear Cover

4 Hold the MSAM cardholder panel, grasp firmly and pull upward to expose the MSAM slots.

Figure 11 Removing VX 520 Color D/E CTLS MSAM Cover

5 Remove any previously installed MSAM card by sliding the card from the MSAM cardholder.

6 Install an MSAM card by carefully sliding it into the slot until it is fully inserted.

Figure 12 Installing an MSAM Card in a VX 520 Color D/E CTLS Terminal



Before inserting the MSAM card, position it as shown in Figure 12, with the card's gold contacts facing down. The cardholder connector base has an image resembling the notched corner of an MSAM card to ensure the card is positioned correctly.

7 Close the MSAM cardholder panel, and then replace the terminal rear cover.

Connecting Optional Devices

The VX 520 Color D/E CTLS terminal supports some peripheral devices designed for use with electronic point-of-sale terminals.



Before connecting any peripheral device, remove the power cord from the terminal. Reconnect the power cord only *after* you are finished connecting the peripheral device(s). For complete information about peripheral installation and use, refer to the user documentation supplied with those devices.

Different terminals support different devices, so for more information about optional devices, please contact your VeriFone distributor.

Optional Device The VX 520 Color D/E CTLS terminal has a port that can operate either as a PIN pad port or an RS-232 port, depending on the power source available.

Connecting the PIN Pad or Smart Card Reader to the VX 520 Color D/E CTLS



When the VX 520 Color D/E CTLS terminal is powered via the corded power supply, the terminal provides 8V DC, 2.25A or 9.3V DC, 4.0A. This power will drive most VeriFone accessories. Contact your local VeriFone representative for more information.

- 1 Remove the VX 520 Color D/E CTLS terminal rear cover.
- 2 Insert the RJ-45-type connector of the PIN pad or smart card reader into the port of the peripheral device.

To install a PINpad 101, PINpad 201, or PINpad 1000, position and insert the grommet to secure the cable connection.

If a cable is not already connected to the smart card reader or PIN pad, insert the small modular plug on one end of the interface cable into the optional device's modular jack.

3 Insert the larger RJ-45-type connector on the other end of the PIN pad cable into the PIN pad serial port on the terminal. Figure 13 provides an example of a smart card reader and PIN pad connection to the PIN pad serial port.



Connecting ECRs to the VX 520 Color D/E CTLS

The VX 520 Color D/E CTLS terminal also supports electronic cash registers (ECR). Contact your VeriFone representative or visit the online store at *www.store.verifone.com* for information on these devices.

Figure 14 provides an example of a peripheral connection to the USB port.



ECRs require a separate power source. Before connecting a check reader or similar device, remove the power cord from and ensure that the indicator LED is not lit.

Figure 14 VX 520 Color D/E CTLS Sample ECR Connection

External Printers Supported

Although the VX 520 Color D/E CTLS terminal has an internal thermal printer, it may be convenient to print larger print runs (for example, daily or weekly reports) to an external printer. The VX 520 Color D/E CTLS terminal supports the VeriFone P250, P350, P900, and P950 external printers. Contact your VeriFone representative or visit the online store at *www.store.verifone.com* for information on these devices. External printers connect through the RS-232 port and require a separate power supply.

Connecting the Terminal Power Pack

When you have finished connecting optional peripheral(s), you are ready to connect the VX 520 Color D/E CTLS terminal to the provided power source.

Using an incorrectly rated power supply may damage the terminal or cause it not to work as specified. Before troubleshooting, ensure that the power supply being used to power the terminal matches the requirements specified on the bottom of the terminal. (See Chapter 3, Specifications, for detailed power supply specifications.) Obtain the appropriately rated power supply before continuing with troubleshooting.



1

WARNING

Plugging in the power pack to a power source automatically turns on the terminal.

To connect the terminal power pack

- Remove the terminal rear cover to access the power port.
- 2 Insert the round barrel connector (see Figure 15) into the power port.

Figure 15 VX 520 Color D/E CTLS Power Connection

- 3 Rotate the power plug counter-clockwise and flush against the side panel to lock the plug in place.
- 4 Route the cable in the direction of the arrow above the power port and sling the cable over the underside of the thermal paper container.
- 5 Close the terminal rear cover.

6 Plug the AC power cord into a wall outlet or powered surge protector.



G Do not plug the power pack into an outdoor outlet or operate the terminaloutdoors.

Disconnecting the power during a transaction may cause transaction data files not yet stored in terminal memory to be lost.

To protect against possible damage caused by lightning strikes and electrical surges, consider installing a power surge protector.

When the terminal has power, the terminal lights are activated.

If an application is loaded in the terminal, it starts after the initial VeriFone copyright screen and usually displays a unique copyright screen. If no application is loaded in the terminal, **DOWNLOAD NEEDED** appears on screen after the initial VeriFone copyright screen.

Privacy Shield (Optional)

The privacy shield protects the customers' PIN entry from being seen by the cashier or other customers. The illustration (Figure 16) shows an example of a VX 520 Color D/E CTLS with the optional privacy shield.

Figure 16 Optional Privacy Shield



Merchants who install the terminal without the privacy shield must ensure the cardholder's privacy when entering his PIN by positioning the terminal away from open view.

Using the CTLS The VX 520 Color D/E CTLS function is only active when signaled by an application for the conduction of a contactless smart card transaction.

To perform a contactless smart card transaction:

- 1 Gently tap the card onto or hold the card (within 4 cm) against the surface of the RFID canopy (see Figure 17).
- 2 A message prompt in the terminal display accompanied by a short beeping sound indicates a successful transaction.

Figure 17 Using a CTLS Card



- Proper care to ensure that the contactless module is working properly includes:
- Preventing the module from coming into contact with metallic surfaces while in use.

Using the Smart Card Reader

The smart card transaction procedure may vary from one application to another. Verify the procedure with your application provider before performing a smart card transaction.

To conduct a smart card transaction

- **1** Position a smart card with the contacts facing upward (see Figure 18).
- 2 Insert the smart card into the smart card reader slot in a smooth, continuous motion until it seats firmly.
- 3 Remove the card only when the application indicates the transaction is complete.

Figure 18

3 Inserting a Smart Card



Leave the smart card in the card reader until the transaction is complete. Premature card removal will invalidate the transaction. Using the VX 520 Color D/E CTLS terminal supports credit or debit card transactions. Magnetic Card Reader

To conduct a credit or debit card transaction

- 1 Position a magnetic card with the stripe in the card reader and facing inward, toward the keypad.
- 2 To ensure a proper read of the magnetic swipe card, the user should insert the magnetic card from the top of the unit, as shown in Figure 19.
- 3 Swipe the card through the magnetic card reader.

Figure 19 Using the Magnetic Card Reader



Specifications

This chapter discusses power requirements, dimensions, and other specifications of the VX 520 Color D/E CTLS terminal:

Power VX 520 Color D/E CTLS terminal: 8V DC, 2.25A or 9.3V DC, 4.0A

- **DC Power Pack** UL, ITE listed, LPS power supply:
 - a Input rated: 100 240V AC, 50/60 Hz
 - b Output rated: 8V DC, 2.25A or 9.3V DC, 4.0A

Barrel connector polarity:



- **Temperature** Operating temperature: 0° to 40° C (32° to 104° F)
 - Storage temperature: -30° to $+ 60^{\circ}$ C (-22° to 140° F)
 - Relative humidity: 5% to 85%; no condensation

External Dimensions

- Length: 203 mm (7.9 in)
- Width: 85.5 mm (3.4 in)
- Height: 75.5 mm (2.9 in)





Maintenance

The VX 520 Color D/E CTLS terminal has no user-maintainable parts.

Clean the Terminal

To clean the terminal, use a clean cloth slightly dampened with water and a dropor two of mild soap. For stubborn stains, use alcohol or an alcohol-based cleaner.



Never use thinner, trichloroethylene, or ketone-based solvents – they may cause deterioration of plastic or rubber parts.

Do not spray cleaners or other solutions directly onto the keypad or terminal display.

Terminal Contacts

Gently swab the contacts with alcohol or contact cleaner to remove the dirt. It is important that the exposed contacts of the VX 520 Color D/E CTLS terminal stay clean and unbent.



Avoid touching the contacts of the terminal. Finger oils tarnish contacts, causing bad connections. When experiencing a high occurrence of bad or incomplete data transfers, clean the contacts.

Smart Card Reader

Do not attempt to clean the smart card reader. Doing so may void any warranty. For smart card reader service, contact your VeriFone distributor or service provider. MAINTENANCE Smart Card Reader

l





Troubleshooting Guidelines

The troubleshooting guidelines provided in the following section are included to assist you to successfully install and configure your VX 520 Color D/E CTLS terminal. If you have problems operating your VX 520 Color D/E CTLS terminal, please read through these troubleshooting examples.

If the problem persists even after performing the outlined guidelines or if the problem is not described below, contact your local VeriFone representative for assistance. Typical examples of malfunction you may encounter while operating your VX 520 Color D/E CTLS terminal and steps you can take to resolve them are listed.



The VX 520 Color D/E CTLS terminal comes equipped with tamper-evident labels. The VX 520 Color D/E CTLS contains no user serviceable parts. Do not, under any circumstance, attempt to disassemble the terminal. Perform only those adjustments or repairs specified in this guide. For all other services, contact your local VeriFone service provider. Service conducted by parties other than authorized VeriFone representatives may void any warranty.

CAUTION

Using an incorrectly rated power supply may damage the terminal or cause it not to work as specified. Use only a VeriFone-supplied power pack with the correct output ratings. Before troubleshooting, ensure that the power supply being used to power the terminal matches the requirements specified on the bottom of the terminal. (See Specifications for detailed power supply specifications.) Obtain the appropriately rated power supply before continuing with troubleshooting.

Blank Display

When the terminal display screen does not show correct or clearly readable information:

- Check terminal power connection.
- Remove and reapply power to the terminal.
- Check all cable connections and verify that the telephone line is properly connected.
- If the problem persists, contact your local VeriFone service provider.

_	
Terminal Does Not Dial Out	If the terminal does not dial out:
	Check the telephone line connections.
	 Check that the telephone line is working by plugging it into a working telephone and listening for a dial tone.
	 Replace the telephone cable that connects the terminal with a cable you know is working correctly.
	 If the problem persists, contact your local VeriFone service provider.
Printer Paper	If paper jams inside the printer:
Jam	Open the paper roll cover.
	 Remove the damaged paper from the paper roll and clear the feed mechanism.
	Install printer paper.
	 If the problem persists, it may be due to poor paper quality. Install a new roll of higher-quality paper.
	Poor-quality paper may jam the printer. To order high-quality VeriFone paper, refer
Ģ	to Accessories and Documentation.
Keypad Does	to Accessories and Documentation. If the keypad does not respond properly:
Keypad Does Not Respond	
	 If the keypad does not respond properly: Check the terminal display. If it displays the wrong character or nothing at all when you press a key, follow the steps outlined in Transactions Fail To
	 If the keypad does not respond properly: Check the terminal display. If it displays the wrong character or nothing at all when you press a key, follow the steps outlined in Transactions Fail To Process. If pressing a function key does not perform the expected action, refer to the user documentation for that application to ensure you are entering data
Not Respond Peripheral	 If the keypad does not respond properly: Check the terminal display. If it displays the wrong character or nothing at all when you press a key, follow the steps outlined in Transactions Fail To Process. If pressing a function key does not perform the expected action, refer to the user documentation for that application to ensure you are entering data correctly.
Not Respond Peripheral Device Does Not	 If the keypad does not respond properly: Check the terminal display. If it displays the wrong character or nothing at all when you press a key, follow the steps outlined in Transactions Fail To Process. If pressing a function key does not perform the expected action, refer to the user documentation for that application to ensure you are entering data correctly. If the problem persists, contact your local VeriFone representative.
Not Respond Peripheral	 If the keypad does not respond properly: Check the terminal display. If it displays the wrong character or nothing at all when you press a key, follow the steps outlined in Transactions Fail To Process. If pressing a function key does not perform the expected action, refer to the user documentation for that application to ensure you are entering data correctly. If the problem persists, contact your local VeriFone representative. If any peripheral device (PIN pad or smart card reader) does not work properly:
Not Respond Peripheral Device Does Not	 If the keypad does not respond properly: Check the terminal display. If it displays the wrong character or nothing at all when you press a key, follow the steps outlined in Transactions Fail To Process. If pressing a function key does not perform the expected action, refer to the user documentation for that application to ensure you are entering data correctly. If the problem persists, contact your local VeriFone representative. If any peripheral device (PIN pad or smart card reader) does not work properly: Check the power cord connection to the peripheral device. Check that the device connected to the proper port has power and is

TransactionsThere are several reasons why the terminal may not be processing transactions.Fail To ProcessUse the following steps to troubleshoot failures.

Check the Magnetic Card Reader

- Perform a test transaction using one or more different magnetic stripe cards to ensure the problem is not a defective card.
- Ensure that you are swiping cards properly. With the card reader, the black magnetic stripe on the card should face down and inward, toward the keypad and must be inserted from the top of the terminal.
- Process a transaction manually, using the keypad instead of the card reader. If the manual transaction works, the problem may be a defective card reader.
- If the manual transaction does not work, proceed to Check the Telephone Line.
- Contact your VeriFone distributor or service provider.

Check the Smart Card Reader

- Perform a test transaction using several different smart cards to ensure the problem is not a defective card.
- Ensure that the card is inserted correctly and that the card is not removed prematurely.
- Ensure the MSAM cards are properly inserted in the cardholders and that the cardholders are properly secured (see Installing/Replacing MSAM Cards).
- If the manual transaction does not process, proceed to Check the Telephone Line.
- Contact your VeriFone distributor or service provider.

Check the Telephone Line

- Disconnect the telephone line from the terminal and connect it to a working telephone to check for a dial tone. If there is no dial tone, replace the telephone cable.
- If the problem appears to be with the telephone line, check with the party you are trying to call to see if their system is operational. If they are not experiencing difficulties with their line, contact the telephone company and have your line checked.
- If the telephone line works, contact your local VeriFone representative for assistance.

Printer Does Not	If the printer does not work properly:		
Print	Check terminal power connection.		
	 Check if the printer is out of paper and that the roll is properly installed and in the right direction. Open the paper roll cover and install a new roll of printer paper or ensure that the roll is feeding from the bottom. 		
	• Verify that the printer roller and paper roll dust cover are properly installed.		
	• If the problem persists, contact your VeriFone distributor or service provider.		
Terminal Display Does not Show	 Connect the terminal in to a known-good power supply (if you have one) to see if this clears the problem. 		
Correct or Readable Information	 If the problem persists, contact your local VeriFone representative for assistance. 		
Terminal Does Not Start	Make sure you press the ENTER key for approximately 3 seconds, until the unit lights up.		



VeriFone Service and Support

For terminal problems, contact your local VeriFone representative or service provider.

For product service and repair information:

- USA VeriFone Service and Support Group, 1-800-VeriFone (837-4366), Monday - Friday, 8 A.M. - 8 P.M., Eastern time
- International Contact your VeriFone representative

Terminal for Service

Return a Before returning a VX 520 Color D/E CTLS terminal to VeriFone, you must obtain an MRA number. The following procedure describes how to return one or more VX 520 Color D/E CTLS terminals for repair or replacement (U.S. customers only).



International customers are advised to contact their local VeriFone representative for assistance regarding service, return, or replacement of terminals.

To return a terminal 1 for service

Get the following information from the printed labels on the bottom of each VX 520 Color D/E CTLS terminal to be returned:

- Product ID, including the model and part number. For example, "VX 520 Color D/E CTLS" and "Pxxx- xxx-xx," "Mxxx-xx-xxx," or "2xxxx-XX"
- Serial number (S/N xxx-xxx)
- 2 Obtain the MRA numbers by completing one of the following:
 - a Call VeriFone toll-free within the United States at 1-800-VeriFone and follow the automated menu options.
 - Select the MRA option from the automated message. The MRA department is open Monday to Friday, 8 A.M.-8 P.M., Eastern Time.
 - Give the MRA representative the information you gathered in Step 1. If the list of serial numbers is long, you can fax the list, along with the information gathered in Step 1, to the MRA department at 727-953-4172 (U.S.).
 - b Address a fax to "VeriFone MRA Dept." with the model and part number(s)
 - Include a telephone number where you can be reached and your fax number.

- Complete the Inquiry Contact Form at http://www.verifone.com/aboutus/contact/contact_form.cfm.
 - Address the Subject box with to "VeriFone MRA Dept."
 - Reference the model and part number in the Note box.



One MRA number must be issued for each VX 520 Color D/E CTLS terminal you return to VeriFone, even if you are returning several of the same model.

- 3 Describe the problem(s).
- 4 Provide the shipping address where the repaired or replacement unit must be returned.
- 5 Keep a record of the following items:
 - Assigned MRA number(s).
 - VeriFone serial number assigned to the VX 520 Color D/E CTLS terminal you are returning for service or repair (terminal serial numbers are located on the bottom of the unit).
 - Shipping documentation, such as air bill numbers used to trace the shipment.
 - Model(s) returned (model numbers are located on the VeriFone label on the bottom of the VX 520 Color D/E CTLS terminal).

Accessories and VeriFone produces the following accessories and documentation for the VX 520 Color D/E CTLS terminal. When ordering, please refer to the part number in the left column.

- VeriFone online store at www.store.verifone.com
- USA VeriFone Customer Development Center, 800-VeriFone (837-4366), Monday - Friday, 7 A.M. - 8 P.M., Eastern time
- International Contact your VeriFone representative

Printer Paper	VPN PPR 268-001-01-A	40 mm (1.57 in) diameter, 57 mm (2.24 in) wide
Supplementary Hardware	STA252-001-01-A	Swivel stand
That diward	STA252-005-01-A	Wall-mount stand
/eriFone Cleaning Kit	VPN 02746-01	Cleaning kit
Telephone Line Cord	VPN CBL000-001-01-A	2.1 meter (7 foot) telephone line cord, black, with modular RJ-11-type connectors

V

Documentation

VPN DOC252-0xx-EN-A	VX 520 Color D/E CTLS Certifications and Regulations
VPN DOC252-0xx-EN-A	VX 520 Color D/E CTLS Quick Installation Guide
VPN DOC252-0xx-EN-A	VX 520 Color D/E CTLS Reference Manual



VERIFONE SERVICE AND SUPPORT Accessories and Documentation







A

accessories documentation ordering **40** printer paper telephone line cord VeriFone cleaning kit

С

cleaning kit connection ports VX 520 Color D/E CTLS contact VeriFone

D

dial out problems troubleshooting **36** displays troubleshooting **35, 38** documentation **40** acronym definitions **6** conventions **6** ordering **41**

E

electrical considerations 14, 21 electrostatic discharges 21 prevention 21 environmental factors 14 external printers VX 520 Color D/E CTLS RS-232 port connection 25 external printers supported VeriFone external printers 25

installation connecting a PIN pad to VX 520 Color D/E CTLS **24** installation VX 520 Color D/E CTLS connecting a smart card reader to VX 520 Color D/E CTLS 24 connecting optional device(s) 23 connecting the terminal power pack 26 connecting the terminal to a telephone line 19 MSAM cards 21 terminal location 13 unpacking the shipping carton 14 integrated printers paper jams 36 troubleshooting 38 integrated printers VX 520 Color D/E CTLS about the integrated printer paper 19

K

keypads troubleshooting **36**

Μ

maintenance avoid cleaning Smart Card Reader cleaning the terminal cleaning the terminal contacts returning a terminal for repair or replacement MSAM cardholders MSAM cards installation

0

optional devices connecting 23

Ρ

paper for integrated printers **19** paper jams troubleshooting **36** peripheral devices troubleshooting **36** peripherals troubleshooting **36** power packs connecting **26** printer paper 40 mm thermal **40** 49 mm thermal **40** sprocket-fed, carbonized **40** printer paper VX 520 CTLS storage **19** printers troubleshooting **38** privacy shield VX 520 CTLS **27**

S

Service **39** service returning a terminal for repair or replacement specifications VX 520 Color D/E CTLS external dimensions VX 520 Color D/E CTLS power VX 520 Color D/E CTLS power pack VX 520 Color D/E CTLS temperature

Т

technical support 39 contacting VeriFone 39 returning a terminal for repair or replacement 39 telephone line connections 19 telephone line cords ordering 40 terminal features VX 520 Color D/E CTLS general 15 terminals accessories 40 benefits **10** cleaning 33 documentation 40 environmental factors 14 repair 39 replacement 39 troubleshooting 35, 38 VX 520 Color D/E CTLS features 15 transactions VX 520 Color D/E CTLS contactless cards 28 VX 520 Color D/E CTLS magnetic cards 30 VX 520 Color D/E CTLS smart cards 29

troubleshooting displays **35**, keypads **36** peripheral devices peripherals printers **38** terminal transactions terminals **36**,

V

 VX 520 Color D/E CTLS multi-application capability 11 troubleshooting 38
 VX 520 Color D/E CTLS terminals electrical considerations 14






VeriFone, Inc. 2099 Gateway Place, Suite 600 San Jose, CA, 95110 USA Tel: (800) VeriFone (837-4366) www.verifone.com

VX 520 Color D/E CTLS

Installation Guide



LATER