



Platinum™ Remote Control
Model UR73A

To setup:

1. Press and hold Setup until light starts on.
2. Press and release navigation
- TV, VCR, DVD, AUX.
3. Enter 4 digit code from code list.
4. With codes at back of remote door for
- more reference.

THIS DEVICE COMPLIES WITH PART 15 OF THE FCC
RULES. OPERATORS ARE SUBJECT TO THE FOLLOWING
TWO CONDITIONS: (1) THIS DEVICE MAY NOT CAUSE
HARMFUL INTERFERENCE; (2) ANY INTERFERENCE
RECEIVED MUST BE ACCEPTED, INCLUDING
INTERFERENCE THAT MAY CAUSE UNDESIRABLE
OPERATION.

Use Two AAA alkaline batteries.
For use with X10 Transmitters, and Home
Automation Modules. FCC ID: B45 UR73A
©2008, and 4500007. © 2008 X10
X10 Wireless Technology, Inc.
www.x10.com/xpwr Made in China