Platinum™ Remote Control

To set up:

Model UR73A

- 1. Press and hold Setup until light stays on.
- 2. Press and release mode button: (TV, VCR, CBL, AUX).
- 3. Enter 4 digit code from code list.
- 4. Write codes on back of battery door for future reference.

THIS DEVICE COMPLIES WITH PART 15 OF THE FCC RULES. OPERATION IS SUBJECT TO THE FOLLOWING TWO CONDITIONS: (1) THIS DEVICE MAY NOT CAUSE HARMFUL INTERFERENCE, AND (2) THIS DEVICE MUST ACCEPTANY INTERFERENCE RECEIVED, INCLUDING INTERFERENCE THAT MAY CAUSE UNDESIRED OPERATION.

Use Two AAA alkaline batteries.

For use with X10 Transceivers, and Home

Automation Modules.

FCC ID: B4S-UR73A

X10.com, a division of IC: 1632

IC: 1632A-XUR73A

X10 Wireless Technology, Inc.

www.x10.com/support

Made in China