

FCC ID: B5DM514 MODEL BTR-800

The following will be placed in the User's Guide, i.e.

8601 E. Cornhusker Highway

P.O. Box 5578

Lincoln, Nebraska 68505 USA

Telephone 402-467-5321

Fax 402-467-3279

MANDATORY SAFETY INSTRUCTIONS TO INSTALLERS & USERS

1. Use only manufacturer or dealer supplied antenna.

ANTENNA MINIMUM SAFE DISTANCE: = 20 cm

Antenna Gain: zero dbd referenced to a dipole

2. The FEDERAL COMMUNICATIONS COMMISSION has adopted a safety standard for human exposure to RF (Radio Frequency) energy, which is below the OSHA (Occupational Safety and Health Act) limits.
3. To comply with current FCC RF Exposure limits, the antenna must be installed at or exceeding the minimum safe distance shown here, and in accordance with the requirements of the antenna manufacturer or supplier.
4. Antenna substitution: Do Not substitute any antenna for the one supplied by or recommended by the manufacturer or radio dealer. You may be exposing person or persons to harmful radio frequency radiation. You may contact your radio dealer or the manufacturer for further instructions.
5. **WARNING:** Maintain a separation distance from the antenna to person(s) of at least 20 cm.

You, as the qualified end-user of this radio device must control the exposure conditions of bystanders to ensure that the minimum separation distance (above) is maintained between the antenna and nearby persons for satisfying RF Exposure compliance.

The operation of this transmitter must satisfy the requirements of General Population/Uncontrolled Exposure Environment for work-related use. Transmit only when person(s) are at least the minimum distance from the properly installed, externally mounted antenna.