


測定内容/Measurement content

1.測定条件/Measurement condition

- ・測定レイアウト/Measurement layout： 測定環境は以下のレイアウトで測定
The measurement environment is measured with the following layout.



2.測定方向/measurement direction

XY平面

XY plane



(RX-ANT_View)

ZX平面

ZY plane



(RX-ANT_View)

YZ平面

YZ plane



(RX-ANT_View)