


FIGURE 2
PRINTER (M/N: SP C262DNW)
COVER REMOVED #2








FIGURE 5
PRINTER (M/N: SP C262DNW)
MAIN BOARD (SOLDERED SIDE)






FIGURE 7
PRINTER (M/N: SP C262DNW)
CHIP #2 AND CRYSTAL #2 ON MAIN BOARD





FIGURE 9
PRINTER (M/N: SP C262DNW)
SIGNAL BOARD (SOLDERED SIDE)









FIGURE 12
PRINTER (M/N: SP C262DNW)
POWER BOARD #1 (SOLDERED SIDE)






FIGURE 14
PRINTER (M/N: SP C262DNW)
POWER BOARD #2 (SOLDERED SIDE)




FIGURE 15
PRINTER (M/N: SP C262DNW)
WIFI BOARD (COMPONENT SIDE)




FIGURE 16
PRINTER (M/N: SP C262DNW)
WIFI BOARD (SOLDERED SIDE)




FIGURE 17
PRINTER (M/N: SP C262DNW)
WIFI LABEL



FIGURE 18
PRINTER (M/N: SP C262DNw)
MOTO #1





FIGURE 20 PRINTER (M/N: SP C262DNw) MOTO #3






FIGURE 22 PRINTER (M/N: SP C262DNw) PANEL COVER REMOVED





FIGURE 24
PRINTER (M/N: SP C262DNW)
PANEL BOARD (SOLDERED SIDE)






FIGURE 26
PRINTER (M/N: SP C262DNW)
NFC BOARD (SOLDERED SIDE)



