



1TX ANT 3 26-Tone RU Index 8






IN-BAND REFERENCE LEVEL




OUT-OF-BAND MID CHANNEL




HIGH CHANNEL 9 BANDEDGE



OUT-OF-BAND HIGH CHANNEL 9




HIGH CHANNEL 10 BANDEDGE




OUT-OF-BAND HIGH CHANNEL 10




HIGH CHANNEL 11 BANDEDGE




OUT-OF-BAND HIGH CHANNEL 11




HIGH CHANNEL 12 BANDEDGE



OUT-OF-BAND HIGH CHANNEL 12





HIGH CHANNEL 13 BANDEDGE




OUT-OF-BAND HIGH CHANNEL 13

1TX ANT 3 242-Tone RU Index 61






MID CHANNEL REFERENCE LEVEL



OUT-OF-BAND MID CHANNEL




HIGH CHANNEL 9 BANDEDGE




OUT-OF-BAND HIGH CHANNEL 9




HIGH CHANNEL 10 BANDEDGE



OUT-OF-BAND HIGH CHANNEL 10




HIGH CHANNEL 11 BANDEDGE




OUT-OF-BAND HIGH CHANNEL 11




HIGH CHANNEL 12 BANDEDGE



OUT-OF-BAND HIGH CHANNEL 12




HIGH CHANNEL 13 BANDEDGE




OUT-OF-BAND HIGH CHANNEL 13


9.6.5. 802.11ax HE20 OFDMA MODE 2TX

ANT 4 + ANT 3 2TX 26-Tones, RU Index 0





MID CHANNEL REFERENCE LEVEL ANT 4




OUT-OF-BAND MID CHANNEL ANT 4



HIGH CHANNEL 9 BANDEDGE ANT 4



OUT-OF-BAND HIGH CHANNEL 9 ANT 4




HIGH CHANNEL 10 BANDEDGE ANT 4



OUT-OF-BAND HIGH CHANNEL 10 ANT 4




HIGH CHANNEL 11 BANDEDGE ANT 4



OUT-OF-BAND HIGH CHANNEL 11 ANT 4




HIGH CHANNEL 12 BANDEDGE ANT 4



OUT-OF-BAND HIGH CHANNEL 12 ANT 4



HIGH CHANNEL 13 BANDEDGE ANT 4




OUT-OF-BAND HIGH CHANNEL 13 ANT 4



LOW CHANNEL 1 BANEDGE ANT 3




OUT-OF-BAND LOW CHANNEL 1 ANT 3




LOW CHANNEL 2 BANEDGE ANT 3




OUT-OF-BAND LOW CHANNEL 2 ANT 3




LOW CHANNEL 3 BANEDGE ANT 3




OUT-OF-BAND LOW CHANNEL 3 ANT 3




MID CHANNEL REFERENCE LEVEL ANT 3




OUT-OF-BAND MID CHANNEL ANT 3



HIGH CHANNEL 9 BANDEDGE ANT 3



OUT-OF-BAND HIGH CHANNEL 9 ANT 3



HIGH CHANNEL 10 BANDEDGE ANT 3




OUT-OF-BAND HIGH CHANNEL 10 ANT 3




HIGH CHANNEL 11 BANDEDGE ANT 3



OUT-OF-BAND HIGH CHANNEL 11 ANT 3




HIGH CHANNEL 12 BANDEDGE ANT 3



OUT-OF-BAND HIGH CHANNEL 12 ANT 3





HIGH CHANNEL 13 BANDEDGE ANT 3




OUT-OF-BAND HIGH CHANNEL 13 ANT 3

ANT 4 + ANT 3 2TX 26-Tones, RU Index 4






MID CHANNEL REFERENCE LEVEL ANT 4



OUT-OF-BAND MID CHANNEL ANT 4



HIGH CHANNEL 9 BANDEGE ANT 4



OUT-OF-BAND HIGH CHANNEL 9 ANT 4



HIGH CHANNEL 10 BANDEGE ANT 4



OUT-OF-BAND HIGH CHANNEL 10 ANT 4



HIGH CHANNEL 11 BANDEDGE ANT 4



OUT-OF-BAND HIGH CHANNEL 11 ANT 4




HIGH CHANNEL 12 BANDEDGE ANT 4



OUT-OF-BAND HIGH CHANNEL 12 ANT 4



HIGH CHANNEL 13 BANDEDGE ANT 4




OUT-OF-BAND HIGH CHANNEL 13 ANT 4



LOW CHANNEL 1 BANDEDGE ANT 3



OUT-OF-BAND LOW CHANNEL 1 ANT 3



LOW CHANNEL 2 BANDEDGE ANT 3




OUT-OF-BAND LOW CHANNEL 2 ANT 3




LOW CHANNEL 3 BANDEDGE ANT 3



OUT-OF-BAND LOW CHANNEL 3 ANT 3



MID CHANNEL REFERENCE LEVEL ANT 3




OUT-OF-BAND MID CHANNEL ANT 3




HIGH CHANNEL 9 BANDEDGE ANT 3



OUT-OF-BAND HIGH CHANNEL 9 ANT 3




HIGH CHANNEL 10 BANDEDGE ANT 3




OUT-OF-BAND HIGH CHANNEL 10 ANT 3



HIGH CHANNEL 11 BANDEDGE ANT 3



OUT-OF-BAND HIGH CHANNEL 11 ANT 3




HIGH CHANNEL 12 BANDEDGE ANT 3



OUT-OF-BAND HIGH CHANNEL 12 ANT 3





HIGH CHANNEL 13 BANDEDGE ANT 3




OUT-OF-BAND HIGH CHANNEL 13 ANT 3

ANT 4 + ANT 3 2TX 26-Tones, RU Index 8






MID CHANNEL REFERENCE LEVEL ANT 4



OUT-OF-BAND MID CHANNEL ANT 4




HIGH CHANNEL 9 BANDEDGE ANT 4



OUT-OF-BAND HIGH CHANNEL 9 ANT 4




HIGH CHANNEL 10 BANDEDGE ANT 4



OUT-OF-BAND HIGH CHANNEL 10 ANT 4



HIGH CHANNEL 11 BANDEDGE ANT 4




OUT-OF-BAND HIGH CHANNEL 11 ANT 4




HIGH CHANNEL 12 BANDEDGE ANT 4



OUT-OF-BAND HIGH CHANNEL 12 ANT 4




HIGH CHANNEL 13 BANDEDGE ANT 4




OUT-OF-BAND HIGH CHANNEL 13 ANT 4



LOW CHANNEL 1 BANDEDGE ANT 3




OUT-OF-BAND LOW CHANNEL 1 ANT 3




LOW CHANNEL 2 BANDEDGE ANT 3




OUT-OF-BAND LOW CHANNEL 2 ANT 3




LOW CHANNEL 3 BANDEDGE ANT 3




OUT-OF-BAND LOW CHANNEL 3 ANT 3



MID CHANNEL REFERENCE LEVEL ANT 3




OUT-OF-BAND MID CHANNEL ANT 3




HIGH CHANNEL 9 BANDEDGE ANT 3



OUT-OF-BAND HIGH CHANNEL 9 ANT 3



HIGH CHANNEL 10 BANDEDGE ANT 3



OUT-OF-BAND HIGH CHANNEL 10 ANT 3