

Note: MSS not supported by A3297

A3295, A3296, A3297


Back Plate






A3295, A3296, A3297

Battery - Back




A3295, A3296, A3297

ANT4 Front




A3295, A3296, A3297

ANT4 Back




A3295, A3296, A3297

Flex Assembly with Proximity Sensor,
Microphone and FaceTime Camera -
Front




A3295, A3296, A3297

Flex Assembly with Proximity Sensor,
Microphone and FaceTime Camera -
Back




A3295, A3296, A3297

Rear Camera - Front




A3295, A3296, A3297

Rear Camera - Back



A3295, A3296, A3297

Top Speaker and Flex Assembly
with ANT2, ANT8/UWB1, ANT10,
ANT6/SharedUWBO - Front



A3295, A3296, A3297

Top Speaker and Flex Assembly
with ANT2, ANT8/UWB1, ANT10,
ANT6/SharedUWBO - Back

