


A1458

Front


Home button, FaceTime camera



A1458

Front - Right Side

Volume up/Down button, Silent/Screen rotation lock switch



A1458

Front - Top side

Power/Sleep/Wake button, Headphone jack



A1458

Front - Left side



A1458

Front - Bottom side

Home button, I/O Connector



A1458

Back

Power/Sleep/Wake button, iSight camera,
Headphone jack, I/O Connector, Regulatory label,
Speaker, Volume up/down button,
Silent/Screen rotation lock switch

