





3TX Antenna WF4 + Antenna WF3 + Antenna WF2 CDD Mode









HIGH CHANNEL 7 BANDEDGE WF4




OUT-OF-BAND HIGH CHANNEL 7 WF4




HIGH CHANNEL 8 BANDEDGE WF4




OUT-OF-BAND HIGH CHANNEL 8 WF4




HIGH CHANNEL 9 BANDEDGE WF4




OUT-OF-BAND HIGH CHANNEL 9 WF4




HIGH CHANNEL 10 BANDEDGE WF4




OUT-OF-BAND HIGH CHANNEL 10 WF4




HIGH CHANNEL 11 BANDEDGE WF4




OUT-OF-BAND HIGH CHANNEL 11 WF4




HIGH CHANNEL 12 BANDEDGE WF4




OUT-OF-BAND HIGH CHANNEL 12 WF4




HIGH CHANNEL 13 BANDEDGE WF4




OUT-OF-BAND HIGH CHANNEL 13 WF4




LOW CHANNEL 1 BANDEDGE WF3




OUT-OF-BAND LOW CHANNEL 1 WF3




LOW CHANNEL 2 BANDEDGE WF3




OUT-OF-BAND LOW CHANNEL 2 WF3




LOW CHANNEL 3 BANDEDGE WF3




OUT-OF-BAND LOW CHANNEL 3 WF3




LOW CHANNEL 4 BANDEDGE WF3




OUT-OF-BAND LOW CHANNEL 4 WF3




LOW CHANNEL 5 BANDEDGE WF3




OUT-OF-BAND LOW CHANNEL 5 WF3







HIGH CHANNEL 9 BANDEDGE WF3




OUT-OF-BAND HIGH CHANNEL 9 WF3




HIGH CHANNEL 10 BANDEDGE WF3



OUT-OF-BAND HIGH CHANNEL 10 WF3



HIGH CHANNEL 11 BANDEDGE WF3



OUT-OF-BAND HIGH CHANNEL 11 WF3

