





2TX Antenna WF3 + Antenna WF2 BF mode




LOW CHANNEL 4 BANDEDGE WF3




OUT-OF-BAND LOW CHANNEL 4 WF3




IN-BAND REFERENCE LEVEL WF3




OUT-OF-BAND MID CHANNEL WF3





HIGH CHANNEL 8 BANDEDGE WF3





OUT-OF-BAND HIGH CHANNEL 8 WF3













HIGH CHANNEL 10 BANDEDGE WF2




OUT-OF-BAND HIGH CHANNEL 10 WF2




HIGH CHANNEL 11 BANDEDGE WF2




OUT-OF-BAND HIGH CHANNEL 11 WF2




HIGH CHANNEL 12 BANDEDGE WF2




OUT-OF-BAND HIGH CHANNEL 12 WF2




3TX Antenna WF4 + Antenna WF3 + Antenna WF2 CDD Mode







LOW CHANNEL 4 BANDEDGE WF4




OUT-OF-BAND LOW CHANNEL 4 WF4




IN-BAND REFERENCE LEVEL WF4




OUT-OF-BAND MID CHANNEL 4 WF4




HIGH CHANNEL 8 BANDEDGE WF4




OUT-OF-BAND HIGH CHANNEL 8 WF4



HIGH CHANNEL 9 BANDEDGE WF4




OUT-OF-BAND HIGH CHANNEL 9 WF4




HIGH CHANNEL 10 BANDEDGE WF4



OUT-OF-BAND HIGH CHANNEL 10 WF4



HIGH CHANNEL 11 BANDEDGE WF4



OUT-OF-BAND HIGH CHANNEL 11 WF4