



Britecell Plus TFAM26 Tune-Up Procedure

Gain for the Britecell Plus TFAM26 is set at the factory and no provisions are made for user accessible controls. Output power is a function of the input power and the fixed gain of the TFAM26.

The user should provide a input signal that will produce an output power not exceeding the levels included in the product data sheet for the medium power remote.