

MMR8 Tune-Up Procedure

Gain for the MMR8 is set at the factory and no provisions are made for user accessible controls. Output power is a function of the input power and the fixed gain of the MMR8.

The user should provide an input signal that will produce an output power not exceeding the levels included in the product data sheet for the MMR8 remote.