



View 1

< Inside EUT >




View 2

< LCD Front >




View 3

< LCD Rear >




View 4

< LCD Label >




View 6

< Main Board Rear >




View 8

< Power Board Rear >




View 9

< CTRL Front >



View 10

< CTRL Board Rear >



A black LG TV remote control (model AK63715608) is shown lying on a light-colored, textured surface. The remote features a red power button at the bottom left, a numeric keypad, and various function buttons including VOL, LIST, FAV, AUDIO, MUTE, INFO, PICTURE, SETTINGS, OK, SLEEP, EXIT, and a Simpelink button. The LG logo and model number are printed at the top.


View 12

< Remote Control >



View 13

< IR Board Front >



View 14

< IR Board Rear >

