

EUT Internal Photos

Figure 9
Internal View (Removed Side Cover)



Figure 10
Internal View (Removed Top Cover)



Figure 11
Internal View (Removed PCB & Battery)



Figure 12
Internal View (Removed PCB Board)



Figure 13
Internal View



Figure 14
Internal View (Removed Printer Engine Driver)




Figure 15

Internal View (Printer Engine Driver, Front View)




Figure 16

Internal View (Printer Engine Driver, Back View)




Figure 17
Internal View (Main Board, Front View)




Figure 18
Internal View (Main Board, Back View)




Figure 19

Internal View (Power Board, Front View)




Figure 20

Internal View (Power Board, Back View)




Figure 21

Internal View (Control Board, Front View)




Figure 22

Internal View (Control Board, Back View)




Figure 23
Internal View (Battery, Front View)



Figure 24
Internal View (Battery, Back View)



Figure 25
Internal View (BT Module, Front View)



Figure 26
Internal View (BT Module, Back View)

