

Adding a memo (Center key > Tools > Memo)
You can register your own memos here.

Setting your alarm (Center key > Tools > Alarm)
You can set up to 3 alarm clocks to go off at a specified time.

Using your calculator (Center key > Tools > Calculator)
The calculator provides the basic arithmetic functions: addition, subtraction, multiplication and division.

Using the stopwatch (Center key > Tools > Stopwatch)
This option allows you to use the function of a stopwatch.

Converting a unit (Center key > Tools > Unit converter)
This converts many measurements into a unit you want.

World clock (Center key > Tools > World clock)
You can check the current time of Greenwich Mean Time (GMT) and major cities around the world.

Fake call

Settings Menu 8

Changing your profiles (Center key > Settings > Profiles)
You can change your profile **General**, **Silent**, **Vibrate only**, **Outdoor**, **Flight mode** and **Headset**.

This device is not intended for sale in the USA.

Part 15.21 statement
" Change or Modifications that are not expressly approved by the manufacturer could void the user's authority to operate the equipment. “

Part 15.105 statement
This equipment has been tested and found to comply with the limits for a class B digitaldevice, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmfulinterference to radio communications. However, there is no guarantee that interference willnot occur in a particular installation. If this equipment does cause harmful interference or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
-Reorient or relocate the receiving antenna.
-Increase the separation between the equipment and receiver.
-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-Consult the dealer or an experienced radio/TV technician for help.

Using Flight mode
1 Press Center key > Settings > Profiles > Flight mode.
2 Use this function to switch the flight mode On or Off. You will not be able to make calls, send message when the Flight mode is On.

Changing your date & time (Center key > Settings > Date & Time)
You can set functions relating to the date and time.

Changing the language (Center key > Settings > Language)
You can change the language for the display texts in your phone. This change will also affect the language input mode.

Changing your display settings (Center key > Settings > Display)
You can change the settings for the phone display.

Call - You can set the menu relevant to a call by pressing the left soft key [OK] in the Setting menu.

Auto keylock - You can make the key pad locked automatically after some time.

Changing your security settings (Center key > Settings > Security)
Change your security settings to keep your LG-A165 and the important information it holds protected.

- **PIN code request:** Choose a PIN code to be requested when you turn your phone on.
- **Phone lock:** Choose a security code to lock your phone, **When power on**, **When SIM changed** or **Immediately**.
- **Call barring**
- **Fixed dial number**

- **Anti Theft Mobile Tracker:**When the handset is stolen, handset sends the SMS to the numbers configured by real owner. User has to configure the ATMT settings with name, primary phone number, secondary number. User has to Set ATMT ON to activate the ATMT feature. Default ATMT code is “0000”. ATMT SMS will contain information about the stolen phone IMEI, current location & number of the person who is using that handset.
- **Change codes:** Changing your **security code** or **PIN2 code** or PIN code, enter the old code followed by the new code.

Power save (Center key > Settings > Power save)
If you set **Always on**, you can save the battery power when you don't use the phone. Choose to switch the power save settings **Always on**, **Night only** or **Off**.

Changing your USB connection
1 Press Center key > Settings > USB connection.
2 Make your change to **Mass storage**, **PC suite** or **Always ask**. (Default Always ask will be selected)

Network selection - You can also select a network manually and set a network.

Resetting your phone (Menu > Settings > Reset settings)
Use **Reset** to reset all the settings to their factory definitions. You need the security code to activate this function. The default number is “0000”.

Memory status - You can check free space and memory usage of phone, SIM card and external memory (if inserted).

Part 15 Class B Compliance
This device and its accessories comply with part15 of FCC rules. Operation is subject to the following two conditions:
(1) This device & its accessories may not cause harmful interference.
(2) This device & its accessories must accept any interference received, including interference that may cause undesired operation.

Body-worn Operation
This device has been tested for typical body-worn operations with the distance of 0.79inches (2.0cm) from the user’s body. To comply with FCC RF exposure requirements, a minimum separation distance of 0.79inches(2.0cm) must be maintained from the user's body. Additionally, Belt clips, holsters & other body-worn accessories may not contain